

Installation Manual

Go with the flow.

alamarinjet



AJ 340

Table of contents

1. Introduction	1
1.1. Safety precautions	1
1.2. Symbols	1
2. General description of installation	3
3. Bottom adapter and transom adapter	5
4. Installation on an aluminium boat	9
4.1. Preparations for installing the bottom adapter and transom adapter	9
4.2. Installing the bottom adapter	12
5. Installation on a boat made from some other material	13
5.1. Preparations for installing the bottom adapter and transom adapter	13
5.2. Installing the bottom adapter	16
6. Attaching the propulsion unit	19
6.1. Preparations	19
6.2. Attaching the frame	19
6.3. Installing the transom adapter	21
6.4. Installing the reversing deflector	22
6.5. Installing the bearings and lubrication system	24
6.5.1. Front bearing	24
6.5.2. Rear bearing	25
6.6. Attaching the hydraulic cylinder	31
6.7. Attaching the hydraulic pump	34
6.8. Installing the cooling line for hydraulic cylinder oil	36
6.9. Intake screen	37
7. Installing the control system	39
7.1. Connecting the reversing deflector to the control system	39
7.1.1. Connecting the control cables	41
7.1.2. Cylinder adjustment	43
7.2. Connecting the steering nozzle to the control system	45
8. Engine installation	47
9. Antifouling	49
Appendix 1. Grease recommendations	51
Appendix 2. Oil recommendations	52
Appendix 3. Tightening torques	53
Appendix 4. Control system hydraulic line	54
Appendix 5. Connecting rod for multi-installation H2-042	57
Appendix 6. Control System	58
Appendix 7. Lever movement ranges	60
Appendix 8. Adapter dimensions	62
Appendix 9. Dimensions of the holes to be cut	64



WARRANTY TERMS

Warranty for the Alamarin-Jet products is 12 months from the first sea trial. However no longer than 18 months from the date of delivery from our factory.

Alamarin-Jet Warranty covers defects in Alamarin-Jet workmanship and materials for the Warranty period. Alamarin-Jet warranty terms will not cover normal part wear nor following cases with external source of issue: incorrect installation, damage caused by outside affect, vessel overloading, misuse, abnormal wear and tear, accident, improper application, improper transportation or storage, natural calamity, unsuitable water conditions, lack of maintenance or neglecting correct procedures described in Alamarin-Jet manuals.

Any Alamarin-Jet product that is serviced, repaired or altered in any way by anyone other than party certified by Alamarin-Jet will not be covered by the warranty terms. Modifying or repairing Alamarin-Jet products with any other than original Alamarin-Jet parts will lead immediate invalidation of Alamarin-Jet product warranty.

Alamarin-Jet Warranty terms excludes indirect costs: Crane rent, docking, warping, towing, assistance of yard crew and services, loss of profit, travel, hotel charges, daily allowances and waiting time, expenses of unauthorized repair work of Alamarin-Jet products, expenses caused by failure of the jet to other components inside or outside the vessel, damages to any third parties, injuries, or any other inconveniences.

In order for warranty decision, Alamarin-Jet must receive defected parts with comprehensive failure description attached and transportation charges covered by the purchaser to Alamarin-Jet for inspection. Based on given details and inspected product, Alamarin-Jet reserves rights to define whether the case is under warranty. After inspection Alamarin-Jet will provide documented description for the customer regarding the case.

In case replacement parts are needed before Alamarin-Jet has analyzed the returned parts, purchaser buys new replacement parts. After confirming potential warranty decision, Alamarin-Jet will provide credit note covering the parts under warranty. All products and parts removed or replaced under the Warranty shall become property of Alamarin-Jet.

Alamarin-Jet reserves exclusive right for Alamarin-Jet warranty terms and no other person or distributor is authorized to modify this Warranty or give any other Warranty on behalf of Alamarin-Jet.

Alamarin-Jet Oy reserves its right to change, amend, add or delete any of the Terms and Conditions without prior notice. Any disputes are to be settled according to Finnish law by arbitration in Helsinki, Finland according to the rules of the International Chamber of Commerce and in accordance with Finnish legislation of Arbitration.

2017/5/10

GO WITH THE FLOW

1. Introduction

This is the installation manual for Alamarin-Jet's AJ 340 water jet propulsion unit. This manual is intended for mechanics who install the Alamarin-Jet water jet propulsion unit to a suitable boat.

© Alamarin-Jet Oy

Tuomisentie 16
FI-62300 Härmä, Finland
Telephone: +358 10 7745 260
Fax: +358 10 7745 269
Internet: www.alamarinjet.com

All rights reserved.

The information in this manual may not be copied, published or reproduced in any way whatsoever, or exploited for commercial purposes, without express written permission from Alamarin-Jet Oy.

The information in this manual is subject to change without notice. Alamarin-Jet Oy reserves the right to modify the contents without notice.

1.1. Safety precautions




Read these instructions carefully before carrying out any procedures. Always follow these instructions and the safety precautions shown below.








- Only a person with adequate training is allowed to carry out the procedures described in this manual.
- The person carrying out the procedures must always wear the appropriate protective equipment.
- The work premises must be sufficiently large, safe and well-lit.
- The tools that are to be used must be clean and appropriate for the intended purpose.

1.2. Symbols

Please refer to table 1 for a description of the symbols used in this manual.

Table 1. The symbols used in the manual

Icon	Description
	DANGER Negligence in the performance of a procedure can cause a threat to your life.
	WARNING Negligence in the performance of the procedures can lead to personal injury, breakdown of equipment, or serious malfunction of the equipment.
	CAUTION The procedure involves minor danger or a possibility of minor damage to equipment.

Icon	Description
	WARRANTY The warranty is voided if the procedure is carried out incorrectly.
	NOTE Important notice or fact.
	TIP Additional information that facilitates the performance of work or a procedure.
	CARRIED OUT BY ONE PERSON One person can carry out the procedure.
	CARRIED OUT BY TWO PERSONS Two persons must carry out the procedure.
	INDICATOR ARROW
	ARROW DESCRIBING MOTION

Please note that this instruction uses the terms "jet" and "jet propulsion unit". They mainly refer to the same thing.

2. General description of installation

Alamarin-Jet water jet propulsion units can be installed on a reinforced plastic, aluminium, steel, polyethylene, or wooden boat.

Perform the installation in the following order:

1. Prepare the boat's hull for installation and install the bottom adapter (section 4. *Installation on an aluminium boat*, page 9 and section 5. *Installation on a boat made from some other material*, page 13).
2. Attach the propulsion unit and install the transom adapter (section 6. *Attaching the propulsion unit*, page 19).
3. Install the control system (section 7. *Installing the control system*, page 39).
4. Install the engine (section 8. *Engine installation*, page 47).
5. Paint the propulsion unit with antifouling paint (section 9. *Antifouling*, page 49).

This is only necessary if the boat is used in waterways where organisms are likely to attach themselves to the propulsion unit.

3. Bottom adapter and transom adapter

The Alamarin-Jet water jet propulsion unit is installed on the boat using a bottom adapter and a transom adapter.




Figure 1. Adapters

The aluminium bottom adapter is suitable for flat-bottom installation as is. The bottom adapter is available in versions suitable for bolted and welded installations. Their difference is in the bolt holes drilled in the bolt installation piece. There are separate adapters available for 5° installations and 0° installations (see appendix 8. *Adapter dimensions*, page 62).

The aluminium transom adapter connects the propulsion unit to the boat's stern. The angle of the transom adapter relative to the bottom adapter is either 95° or 90° depending on the chosen installation angle (figure 2).




Figure 2. Installation angles

Installation direction of the bottom adapter

The bottom adapter must be installed in the correct orientation. The following figures show the correct orientation of the bottom adapter relative the boat's bow and transom.




Figure 3. Correct orientation of the bottom adapter, 5 degree installation

- A The boat's bow
- B The boat's transom




Figure 4. Correct orientation of the bottom adapter, 0 degree installation

- A The boat's bow
- B The boat's transom

4. Installation on an aluminium boat

4.1. Preparations for installing the bottom adapter and transom adapter

This section explains the preparations required by the welded installation of the bottom adapter and transom adapter. Do not attach the transom adapter to the boat's transom until the jet has been attached to the bottom adapter installed in the bottom of the boat.

In order to attach the adapters, cut holes of a suitable size to the transom and bottom of the boat for attachment. The bottom adapter can be welded onto aluminium boats. In welded installation, the bottom adapter is welded to the flat bottom of the boat's hull. The transom adapter is always bolted to the transom, regardless of the boat's hull material.




Figure 5. Bottom adapter and transom adapter holes in the hull

Cut a hole in the bottom of the boat for the bottom adapter (figure 5, point B), and cut a hole in the transom for the transom adapter (figure 5, point A).

The dimensions of the hole in the bottom must match the outer dimensions of the bottom adapter's installation flange, to ensure that the clearance between them is as small as possible. The bottom adapter must be installed in such a way that its bottom surface is flush with the boat's flat bottom (figure 6).




Figure 6. Bottom adapter in the flat bottom of the boat

The distance and angle between the bottom adapter and the transom adapter holes must be dimensioned precisely to enable the installation of the propulsion unit. The figure below (figure 7) illustrates the positions of the holes in a longitudinal cross-section of the boat. The dimensions are from the angle formed by the transom and flat bottom of the boat's exterior to the edge of the hole to be cut.




Figure 7. Hole positions in the boat hull (welded installation)

- A Transom adapter
- B Bottom adapter
- C The angle formed by the transom and bottom of the boat outside the boat's hull. The thickness of the boat hull shown in the figure is illustrative and does not correspond to the actual thickness of the boat hull.

The holes should be positioned on the centreline of the boat (single installation) or on straight lines parallel to the keel line (twin installation). The installation surface of the transom adapter must always be perpendicular to the jet's impeller shaft (figure 2). See appendix 9. *Dimensions of the holes to be cut*, page 64.




Figure 8. Hole position in relation to keel line

- A Transom adapter hole
- B Bottom adapter hole
- C Keel line
- D Triangular plate

Cut a triangular hole in front of the bottom adapter (figure 8, point D). The length of the hole should be 700 mm as measured in the direction of the keel. Fill the hole with the hull material of the boat.

Tentatively fit the adapters in the boat hull before the final installation and ensure that they sit firmly in place in relation to the edges of the cut holes, and that the angle between them enables the installation of the propulsion unit.

**NOTE!**

The lower surface of the bottom adapter must be level with the outer surface of the boat's flat bottom (figure 6).

The edge of the bottom adapter must be parallel with the boat's keel (= the edge of the hole).

The distance and angle between the bottom adapter and transom adapter must be dimensioned carefully to enable the installation of the jet.

If this is not the case, the boat's bottom will have differences in elevation that may cause ventilation or cavitation.

4.2. Installing the bottom adapter

Before installation, cut a hole in the bottom of the boat (section 4.1.

Preparations for installing the bottom adapter and transom adapter, page 9).

The aluminium bottom adapter can be attached to an aluminium boat hull by welding. Bolted installation is also possible, but welding provides certain benefits over using bolts:

- A good welded seam seals the seam between the bottom adapter and boat hull.
 - In this way, the bottom adapter becomes a fixed part of the hull, which minimises the number of possible leaks and ensures a more balanced power transmission between the propulsion unit and hull.
1. Weld the bottom adapter to the hull from the inside and outside in a waterproof manner.
 2. Grind the weld seams. Any uneven spots at the bottom must be trimmed by caulking, for example.

The bolted installation of the bottom adapter is explained in section 5.

Installation on a boat made from some other material, page 13.

5. Installation on a boat made from some other material

5.1. Preparations for installing the bottom adapter and transom adapter

This section explains the preparations required by the installation of the bottom adapter and transom adapter on a boat made from a material other than aluminium. Do not attach the transom adapter to the boat's transom until the jet has been attached to the bottom adapter connected to the bottom of the boat.

In order to attach the mounting template and transom adapter, cut holes of a suitable size to the transom and bottom of the boat for attachment.



NOTE!

Sandwich laminate boats:

The installation area of the propulsion unit must be solid laminate. Bevel the core material of the sandwich laminate surrounding the area to ensure that the structure transitions from sandwich laminate to solid laminate in a sufficiently even manner.




Figure 9. Bottom adapter and transom adapter holes in the hull

Bolting the bottom adapter to the boat's hull requires the installation area to be shaped differently than that of the welded installation used for aluminium boats. The flat bottom of the boat must feature an indentation to ensure that the lower surface of the bottom adapter is installed flush with the outer surface of the boat's flat bottom. The cross-section below (figure 10) indicates how the bottom adapter settles in the indentation in the flat bottom so that the lower surface (figure 10, point B) is flush with the lower surface of the flat bottom.




Figure 10. Indentation in the flat bottom

- A Installation surface for the propulsion unit on the bottom adapter
- B Lower surface of the bottom adapter

Cut a hole the size of the external dimensions of the bottom adapter's installation surface for the propulsion unit (figure 10, point A) in the boat's bottom in such a way that the installation surface goes inside the boat, as shown in the cross-section above. The figure below illustrates the positions of the holes measured from the same point.




Figure 11. Hole positions in the boat hull (bolted installation)

- A Transom adapter
- B Bottom adapter
- C The angle formed by the transom and bottom of the boat outside the boat's hull
- D The thickness of the boat hull shown in the figure is illustrative and does not correspond to the actual thickness of the boat hull.

The holes should be positioned on the centreline of the boat (single installation) or on straight lines parallel to the keel line (twin installation). The installation surface of the transom adapter must always be perpendicular to the jet's impeller shaft (figure 2). See appendix 9. *Dimensions of the holes to be cut*, page 64).




Figure 12. Hole position in relation to keel line

- A Transom adapter hole
- B Bottom adapter hole
- C Keel line
- D Triangular plate

Cut a triangular hole in front of the bottom adapter (figure 12, point D). The length of the hole should be 700 mm as measured in the direction of the keel. Fill the hole with the hull material of the boat.

Tentatively fit the adapters in the boat hull before the final installation and ensure that they sit firmly in place in relation to the edges of the cut holes, and that the angle between them enables the installation of the propulsion unit.



NOTE!

The lower surface of the bottom adapter must be level with the outer surface of the boat's flat bottom (figure 6).

The edge of the bottom adapter must be parallel with the boat's keel (= the edge of the hole).

The distance and angle between the bottom adapter and transom adapter must be dimensioned carefully to enable the installation of the jet.

If this is not the case, the boat's bottom will have differences in elevation that may cause ventilation or cavitation.

5.2. Installing the bottom adapter

If the material of the boat's hull is something other than aluminium (e.g. polyethylene, steel, wood, reinforced plastic), the bottom adapter must be installed with bolts.

The installation of the bottom adapter can be initiated if a correctly sized hole has been cut in the boat's bottom and the shape of the bottom enables the

installation, section 5.1. *Preparations for installing the bottom adapter and transom adapter*, page 13.

1. Use the bottom adapter to determine and mark the positions of the bolt holes around the hole cut in the boat's bottom.

The bottom adapter is attached to the flat-bottomed area with 24 M12 bolts. However, please note that the bottom adapter must be removed for the duration of drilling the holes.

2. Seal the seam between the bottom adapter and boat bottom with the appropriate sealing compound (e.g. Sikaflex 291i).

Before spreading the sealing compound, ensure that the surfaces to be sealed are sufficiently clean and dry, and as even as possible. In addition to this, each bolt hole must be carefully sealed with sealing compound. Spread sealing compound on the surface of the bottom adapter and the boat's bottom. The quantity applied must be such that when the bottom adapter is attached to the boat's bottom, some compound is squeezed evenly out of the adapter seams, both inside and outside the hull. If sealing compound is not squeezed out of a part of the seam, it must be assumed that the section in question is not tight and sealing compound must be added. The manufacturer's instructions must be observed when using sealing compound.

3. Set the bottom adapter in place so that the bolt holes in the boat's bottom and the bottom adapter are aligned.
4. Apply sealing compound on the bolts and threads, and push the bolts through the holes from outside the boat so that the nuts can be installed inside the boat.
5. Tighten the bolts.

Ask an assistant inside the boat to help you tighten the bolts. Ensure that a sufficient amount of sealing compound is squeezed out of the seams, in accordance with the instructions in step 3.

6. Attaching the propulsion unit

The propulsion unit is attached to the boat one part at a time. Attachment is carried out in the following order:

1. Propulsion unit frame
2. Lubrication system for the bearings
3. Hydraulic cylinder
4. Hydraulic pump
5. Cooling line for hydraulic cylinder oil

6.1. Preparations



Remove the propulsion unit's reversing deflector.



WARNING!

When removing the hydraulic cylinder, the piston rod must not twist 180°. The cylinder will not work properly if that occurs.

6.2. Attaching the frame



Attaching the frame of the propulsion unit to the boat:

1. Ensure that the hole cut for the transom adapter is in the correct position in relation to the propulsion unit frame. If this is not the case, patch or cut the hole to a suitable form.
2. Apply sealing compound (e.g. Sikaflex 291i) on the outer edge of the attachment surface on the bottom of the propulsion unit frame, and on the edge on the intake duct side (figure 13, point A). Sealing compound should also be applied on the installation surface of the bottom adapter.

The propulsion unit frame should be lifted to a position that enables easy lifting into the boat after the sealing compound has been applied.




Figure 13. Installation surface on the bottom of the propulsion unit frame

3. Apply compound in the fastening bolt (20 pcs) holes (figure 13, point B).




Figure 14. Lifting points

4. Lift the propulsion unit frame into place on the bottom adapter and push the fastening bolts into the holes.

The lifting points of the propulsion unit are shown in the figure above (figure 14).

5. Ask your assistant inside the boat to fasten the nuts.

6. Tighten the nuts evenly on opposite sides at the same time, and make sure that some sealing compound is squeezed out on every side.
7. Wipe the excess compound off the outer edges and intake duct.

6.3. Installing the transom adapter

Do not install the transom adapter until you have attached the propulsion unit to the bottom adapter installed in the boat's bottom. The transom of the boat must feature a correctly sized hole for installing the adapter (section 4.1. *Preparations for installing the bottom adapter and transom adapter*, page 9).



CAUTION!

The rotation position of the transom adapter must be correct. If this is not the case, the propulsion unit cannot be installed correctly and the hydraulic cylinder and intermediate rod are subjected to twisting forces.

The adapter is attached to the transom with 20 M12 bolts, for which matching holes must be drilled into the transom.

1. Place the adapter on the transom-side installation flange of the propulsion unit body and mark the positions of the boreholes in the transom.

However, you must remove the transom adapter for the duration of drilling the holes.

2. Drill the holes in the transom.
3. Seal the seam between the adapter and boat transom with the appropriate sealing compound (e.g. Sikaflex 291i).

Before spreading the sealing compound, ensure that the surfaces to be sealed are sufficiently clean and dry, and as even as possible. In addition to this, each bolt hole must be carefully sealed with sealing compound. Spread sealing compound on the surface of the adapter and the transom. The quantity applied must be such that when the bottom adapter is attached to the boat's bottom, the compound is squeezed evenly out of the adapter seams both inside and outside the hull. If sealing compound is not squeezed out of a part of the seam, it must be assumed that the section in question is not tight and sealing compound must be added. The manufacturer's instructions must be observed when using sealing compound.

4. Attach the O-ring seal (figure 15, point A) into the groove in the rim of the transom-side installation flange (figure 15, point B).

Lubricate the o-ring with waterproof petroleum jelly to prevent damage.




Figure 15. Seal ring

- A Seal ring
- B O-ring groove
- C Transom adapter

5. Set the transom adapter in place so that the bolt holes in the boat's transom and the transom adapter are aligned.
6. Apply sealing compound on the bolts and threads, and push the bolts through the holes from outside the boat so that the heads remain outside the boat.
7. Tighten the bolts.

Ask an assistant inside the boat to help you tighten the bolts. Ensure that a sufficient amount of sealing compound is squeezed out of the seams, in accordance with the instructions in step 3.

8. Wipe the excess compound off the outer edges and intake duct.

6.4. Installing the reversing deflector

Attach the reversing deflector to the holes in the stator body with two M24 bolts. There is a plastic bearing and a sleeve between the bolt and the reversing deflector on both sides of the deflector (figure 16).




Figure 16. Reversing deflector sleeve and plastic bearing

1. Lift the reversing deflector into place in such a way that the holes in the deflector and stator body are aligned.
2. Insert locking washers and washers on the bolts, and push the bolts through the holes in the reversing deflector (figure 17).




Figure 17. Attaching the reversing deflector

3. Tighten the bolts.

The tightening torque of the M24 bolt is 250 Nm.

6.5. Installing the bearings and lubrication system



6.5.1. Front bearing

The front bearing carries the axial and radial loads. The bearing is oil-lubricated and the housing is secured with mechanical sealing.

When the shaft rotates, the oil circulates through the reservoir and impurities gather at the bottom of the reservoir on the drain plug magnet.

The oil reservoir included in the system is installed in a suitable place. The need for maintenance (oil change) must be taken into consideration when selecting the location. It must be possible to check the oil level when necessary.

The bearing housing is filled with oil when it is delivered from the factory. The installation must be carefully performed in accordance with the instructions so that the lubrication functions well from the beginning and as little air as possible escapes into the system.

Front bearing installation:

1. Make sure that the oil reservoir is installed (section 6.7. *Attaching the hydraulic pump*, page 34).

The hoses attached to the reservoir connectors are marked IN and OUT. The side of the bearing housing has the corresponding markings (figure 18, A = IN and B = OUT).




Figure 18. Bearing housing connectors

2. Remove the plugs of the bearing housing's IN and OUT connectors, insert the hose from the reservoir to the IN connector and tighten the joint with pipe straps.
3. Pour oil into the reservoir and let the hose fill up for approx. 5 minutes.

The type of oil to use is described in appendix 2. *Oil recommendations*, page 52.

Keep the hose as straight as possible and shake it occasionally to prevent air pockets from forming. The bearing housing is full of oil when oil seeps out of the OUT connector.

4. Clean the OUT connector, connect the system return hose and tighten the joint with pipe straps.
5. Keep adding oil into the reservoir so that as little air as possible drifts into the system.

6.5.2. Rear bearing

The propulsion unit's rear end bearing is either water or grease lubricated, depending on the model. In contrast to the grease-lubricated model, the water-lubricated model may not be used dry. Ample water supply must be ensured to the rear bearing to ensure sufficient lubrication.

Water-lubricated rear bearing

The water-lubricated rear end bearing is an open system, and its maintenance interval depends on the water quality.

The rear end bearing of the grease lubricated model is lubricated with petroleum jelly through a grease nipple. The lubrication channel runs from the grease nipple to the rear bearing housing.

The properties of the grease to use are described in appendix 1. *Grease recommendations*, page 51.

Grease-lubricated rear bearing

The rear bearing is lubricated by an external lubrication hose.

Lubrication of the rear bearing with an external hose

The rear bearing is lubricated by an external lubrication hose that runs through the boat transom (figure 19, point A). The lubrication hose is connected to the stator with an angle fitting (figure 19, point B), through which the lubricant flows into the rear bearing housing.




Figure 19. Lubrication of the rear bearing with an external hose

Installing the external lubrication hose for the rear bearing

The external lubrication hose for the rear bearing is installed in accordance with figure 20. Please note that points A and B in figure 20 are located outside the boat, while points C and D are located inside the boat.

1. Choose a suitable location on the boat transom for the lubrication hose lead-in.

The lead-in should be placed above the waterline. The thickness of the transom at the lead-in should be $T = 5...20$ mm.
2. Drill a $\varnothing 13.5$ mm hole in the location chosen for the lead-in.
3. Place the lead-in connector (figure 20, point B) in the drilled hole in accordance with figure 20 and seal it with sealing compound (such as Sika291i).
4. Tighten connector C in figure 20 to the lead-in connector.
5. Attach the lubrication hose (figure 20, point A) to the lead-in connector and tighten connector D to connector C in accordance with figure 20.
6. Use a plastic hose to form a channel from connector D to a grease nipple.

Alternatively, there can be an automatic lubrication unit at the end of the hose.




Figure 20. Installing the external lubrication hose for the rear bearing

A	Lubrication hose	D	Connector
B	Lead-in connector	E	Transom
C	Connector	F	Waterline

Automatic lubrication unit

The automatic lubrication unit (figure 21) decreases the need for maintenance because it feeds grease to the rear bearing each time the jet's main shaft rotates. The grease going to the rear bearing lubricates the bearing, and it also prevents water from leaking into the bearing housing. The amount of grease is adjusted with a screw in the hydraulic cylinder, which tightens the spring (figure 22). When you loosen the screw, the amount of grease decreases.




Figure 21. Automatic lubrication unit

A	Oil pressure hose from the hydraulic cylinder	D	Grease nipple
B	Scale	E	Grease hose to the lubrication channel
C	Piston		




Figure 22. Adjusting the automatic lubrication unit

Installing the automatic lubrication unit:

1. Choose an appropriate place near the propulsion unit.

Note the lengths of the oil pressure hose and the grease hose. The oil pressure hose (figure 23, point B) must not be tight. Also make sure that the piston (figure 23, point A) can move freely, as it protrudes the length of the scale when the reservoir fills up.




Figure 23. Automatic lubrication unit's piston movement range

2. Use the template delivered with the automatic lubrication unit to make holes for the fastening screws of the rack in a sufficiently sturdy place.
3. Attach the screws delivered with the automatic lubrication unit into place nearly all the way.
4. Put the rack in place.

The rack has slots for the screws. Slide the rack under the screws and tighten them (figure 24) with a spanner.




Figure 24. Automatic lubrication unit's tightening screws

5. Screw the oil pressure hose into either of the outputs shown in figure 25 and plug the unused output. Do not tighten excessively.

Please note that the cylinder must be rotated slightly before the pressure hose can be attached. However, if you want to retain the position of the cable clamp, rotate the plate in accordance with the instructions in section 7.1. *Connecting the reversing deflector to the control system*, page 39.




Figure 25. Attaching the oil pressure hose

6. Attach the grease hose to the connector on the transom of the boat (figure 20, point D).

Feeding

You can adjust the feed as follows:

- If the automatic lubrication unit feeds too much grease (the reservoir empties too soon), reduce the pressure by loosening the adjusting screw (figure 22).
- If the automatic lubrication unit does not feed grease to the rear bearing (cold conditions, thick grease type), increase the pressure by tightening the adjusting screw (figure 22).

The amount of grease fed to the rear bearing must be 0.1 l/100 h (6 cu in/100 h). The grease volume in the unit is 0.3 l (18 cu in). With these settings, the reservoir empties after 300 hours. If you notice that the reservoir empties more quickly or slowly than this, adjust the pressure in the desired direction.

You can fill the reservoir by pushing grease into it with a grease gun through the nipple (figure 21, point D). Then the piston (figure 23, point A) will protrude out of the reservoir.

The properties of the grease to use are described in appendix 1. *Grease recommendations*, page 51.

6.6. Attaching the hydraulic cylinder



Installing the hydraulic cylinder:

1. Treat the threads of the hydraulic cylinder nut (figure 26, point A) with sealing compound (e.g. Sikaflex 291i).
2. Screw the nut all the way down on the thread at the end of the cylinder pipe (figure 26, point B).




Figure 26. Hydraulic cylinder nut

3. Apply sealing compound (e.g. Sikaflex 291i) on the bushing thread of the adapter part in such a way that bushing hole is sealed completely.
4. Screw the hydraulic cylinder onto the adapter bushing (figure figure 27, point B).

The hydraulic cylinder (figure 27, point A) must be screwed far enough onto the threads to reach the correct measurement ($X=31$ mm, figure 29). The correct position of the hydraulic cylinder is determined by the plugs in the cylinder pipe (figure 26, point C), which must face upwards.




Figure 27. Attaching the hydraulic cylinder

5. Tighten the nut against the adapter part.

The nut prevents the hydraulic cylinder from moving on the adapter bushing thread.

6. Ensure that sealing compound has been squeezed out of the seams throughout, and wipe the excess compound off the piston rod.
7. Once you have installed the reversing deflector, install the intermediate bar between the cylinder and the deflector (figure 28).




Figure 28. The intermediate bar between the hydraulic cylinder and the reversing deflector




Figure 29. Installation distance of the hydraulic cylinder

Instructions for adjusting the cylinder's movement area are provided in section 7.1.2. *Cylinder adjustment*, page 43.

6.7. Attaching the hydraulic pump



Attaching the hydraulic pump:

1. Install the pump rack and the pump with screws to the front surface of the bearing housing.

Leave the screws slightly loose. There are a total of four screws, two on both sides (figure 30, points C and D).




Figure 30. Attaching the hydraulic pump

2. Fit the belt in place.
3. Lift the rack by cranking it from point E indicated in figure 30.
4. Tighten the screws.

The tightening torque is 79 Nm.

5. Attach the pressure hose to the connectors (figure 30, point B and figure 31).




Figure 31. Pressure hose connector in the hydraulic cylinder

6. Attach the oil reservoir hose to connector A (figure 30).
7. Install the oil reservoir and its rack to a suitable place above the pump.



Figure 32. Oil reservoir and rack

In figure 32, the 16 mm (5/8") connector (A) is intended for the hose that goes to the pump and the 12 mm (1/2") connector (B) for the return hose.

Checking the oil level

The system must have the right amount of oil. If you need to add oil to the system, add it in the oil reservoir through the cap (figure 33, point C). There is a dipstick on the reservoir cap with markings for maximum and minimum oil levels (figure 33). The type of oil to use is described in appendix 2. *Oil recommendations*, page 52.




Figure 33. Checking the oil level

- A Maximum level
- B Minimum level
- C Cap

6.8. Installing the cooling line for hydraulic cylinder oil



WARNING!

The system's pressure is high during operation (max. 70 bar).

Make sure that the hoses do not rub against sharp edges. The bursting of a pressure hose can cause serious danger.

The oil return hose must run to the reservoir through a cooler. The side of the jet features an oil cooler, which can be used to cool hydraulic cylinder oil.



WARRANTY!

If the cylinder oil is not cooled, the guarantee does not cover pump/cylinder failures due to overheating.

Note the following when installing the line:

- The hose that runs from the cooler to the reservoir should be fitted so that it does not have any "swan necks".

- When you use the propulsion unit for the first time (=after engine installation), check the movement of the reversing deflector and observe the oil level. If the oil level continues to lower even after the line is filled, there is a leak in the system. Find the leak and fix the problem.

6.9. Intake screen



The intake screen (figure 34) is attached with seven M12 screws in front of the intake duct.



Figure 34. Intake screen

Attaching the intake screen:

1. Seal the fixing area in the same manner as when installing the propulsion unit frame.
2. Fit the intake screen in place in the intake duct and tighten the screws in place.

The tightening torque of the screws is 65 Nm.

3. After installation, carefully seal the seams between the screen and the bottom adapter at the back (figure 35) using a sealing compound (such as Sikaflex 291i). This prevents water from entering any cavities between the castings.




Figure 35. Sealing the intake screen

7. Installing the control system

The propulsion unit's control system must be installed correctly. Incorrect installation of the system will reduce performance.

Because the propulsion unit can be used with or without gears, there are various methods of installation.

Installation Options

- The gear is located between the propulsion unit and the engine.
A control with two levers, one of which controls the gearbox and the accelerator and the other the reversing deflector.
- Between the propulsion unit and the engine, there is only the intermediate shaft.
A control with two levers, one of which controls the accelerator and the other the reversing deflector.
- Two propulsion units with a gear.
Two separate controls with two levers or one control with four levers. The two adjacent levers are used to control the gears and accelerators of both engines, and the other two to control the reversing deflectors.

7.1. Connecting the reversing deflector to the control system



The control cylinder of the reversing deflector is used with the lever (figure 36, point A) that is at the end of the cylinder. The lever has a cable terminal when it is delivered from the factory. However, the cable's inlet direction can be different than the standard direction of the cable support (figure 36, point B). You can turn the cable support plate to point in the desired direction in accordance with the cable's inlet direction.




Figure 36. Hydraulic cylinder

Changing the position of the cable support:

1. If the control cable is attached, detach the end of the cable (figure 36, point C) from the cylinder's operating lever and detach the cable fastener from the support plate (figure 36, point D).
2. Loosen the operating lever's fastening screw and pull the lever off the shaft (figure 37).




Figure 37. Removing the operating lever

3. Open the fastening screws (four in total, figure 38) that attach the support plate to the cylinder.

Note that the same screws attach the valve housing to the cylinder pipe. However, if you are careful the valve housing will remain in the cylinder pipe.




Figure 38. Support plate fastening screws

4. Turn the support plate into the desired position and attach it with screws to the valve housing (tightening torque: 10 Nm (7 lb ft)).

Check that the support plate or control cable do not interfere with the rotating intermediate shaft, for example.

The support plate has eight holes, so you can turn the plate at 45° intervals. In figure 39 the plate has been turned 135°.




Figure 39. Turned support plate

5. Place the lever (figure 40, point A) on the operating shaft so that it lies between the limiters on the support plate (figure 40, point B).

The tightening torque of the lever screw is a non-standard 10 Nm (7 lb ft).




Figure 40. Attaching the operating lever

6. Attach the control cable with a fastener (figure 40, point C) to the support plate and with an angle joint (figure 40, point D) to the lever ball screw.

The height of the screw attachments at the end of the lever affects the control system stroke length. See appendix 7. *Lever movement ranges* , page 60.


See the cylinder adjustment instructions in chapter . 7.1.2. *Cylinder adjustment*, page 43.

7.1.1. Connecting the control cables

The control cables are connected from the control system to the reversing deflector, as indicated in figures 41-43 .

Idle running

Both levers (B and C) are in the centre (figure 41)

**Figure 41. Idle running**

- A Accelerator
- B Reversing deflector
- C Steering cylinder's operating lever


Full astern

The control lever is down, the cylinder operating lever on the left (figure 42)

**Figure 42. Full astern**

Full ahead

The control lever is up, the cylinder operating lever on the right (figure 43)

**Figure 43. Full ahead**

7.1.2. Cylinder adjustment

When you start the engine for the first time, make sure that you have oil available to add to the reversing deflector control hydraulic system.

Fill the reservoir with oil before you start the engine. After you start the engine and put it into forward gear, the oil is transferred from the reservoir into the system and the pump automatically removes air from the system. If the oil level decreases in the reservoir, add some oil. There is a dipstick in the reservoir that you can use to check the oil level (figure 33). Occasionally move the hydraulic cylinder's operating lever back and forth (figure 40, point A) so that the cylinder fills with oil.

Adjusting the cylinder:

1. Detach the control cable from the end of the cylinder operating lever (figure 44, point A).




Figure 44. Removing the control cable

2. Loosen the operating lever screw (figure 44, point B) but do not pull the lever off the shaft yet.
3. Place the lever against the limiter on the shaft (figure 45, point A).




Figure 45. Operating shaft and limiter

4. Turn on the engine and put it into gear.
5. Using a wrench, turn the operating shaft (figure 45, point B) 13 mm (0.4") clockwise so that the reversing deflector is down, blocking the jet flow.

If you turn the shaft too much, it will no longer move smoothly, indicating that the cylinder has reached the end of its movement range. If this happens, turn the shaft back slightly.

6. Attach the operating lever to the shaft with a screw and tighten the screw to a torque of 10 Nm (7 lb ft).

Do not tighten the screw too much!

7. Attach the control cable to the screw at the end of the operating lever (figure 44, point A).
8. Use the control system in the cabin to check that the deflector can move to the up and down positions.

In the up position, the deflector does not block the jet flow (figure 46). In the bottom position, the lower edge of the reversing deflector (figure 47) is parallel with the propulsion unit's shaft.




Figure 46. Deflector in the up position




Figure 47. Deflector in the down position

7.2. Connecting the steering nozzle to the control system



There is a lever for the operating device at the end of the nozzle control shaft (figure 48). Operation can be hydraulic, electronic, or mechanical. The most important thing with the operation of the system is that the movement range of the operating device suits the movement range of the lever. The movement range of the lever has to be restricted in case the movement range of the operating device is too long.




Figure 48. Operating device lever



WARNING!

If the movement range of the nozzle operating device is too long, the propulsion system can break down due to overload.

The control lever has holes ready at different heights so that different operating devices can be connected. See appendix 7. *Lever movement ranges*, page 60.

Connecting the lever to the shaft:

1. Clean the surfaces of the shaft and the cone sleeve of grease.
2. Tighten the screws of the cone sleeve, and make them finger-tight.

This way the lever can slide on the shaft and you can find the correct position for it.

3. Find the correct position for the lever, and tighten it to the shaft using the cone sleeve.

Tighten the cone sleeve screws evenly by tightening each screw in turn by several revolutions of the tightening ring while making sure that each screw is tightening the cone sleeve evenly. The self-locking Nord-Lock washers keep the tightened screws in place, which means that a thread-locking agent is not required.

Do not over-tighten the cone sleeve or the cone will stretch the outer ring of the lever. An excessively tightened cone will collapse and lose its grip.

In double installation, the operating device is installed to the steering lever of one jet and the power is transmitted to the steering of the other jet with a connecting rod. The length of the connecting rod is determined by the distance between the jets (appendix 5. *Connecting rod for multi-installation H2-042*, page 57).

8. Engine installation



This section deals with engine installation in relation to the propulsion unit. Otherwise, engine installation must always be carried out in accordance with the engine manufacturer's instructions.

The Alamarin-Jet 340 propulsion unit can be used with various engines, either with gears or with a direct connection to the flywheel adapter. The gear is selected in accordance with the engine power and speed. Check the correct gear by contacting a representative of Alamarin-Jet Oy.



CAUTION!

Before installing the engine, make sure that the gear possibly connected to it is correct. The wrong gear ratio decreases the performance of the propulsion unit or can completely prevent its use.

Aligning the engine with the propulsion unit

Correct sizing and aligning of the intermediate shaft is especially important for the operating life of the whole system. Different intermediate shafts allow different angles and it is imperative that you know the manufacturer's recommendations for maximum angles when installing.

Constant velocity shaft

At both ends of the constant speed shaft, there is a joint based on balls rolling on a spherical surface. Amongst the shafts used with propulsion units, an intermediate shaft of this type allows the most freedom in terms of alignment. The joints can be at angles that are different from each other (figure 49).




Figure 49. Constant velocity shaft

Cardan shaft

The cardan shaft joints are diagonal. This is why alignment is more demanding. To ensure that the shaft rotates without vibration, the joint angles must be equal. Figure 50 shows examples of permitted angle configurations.




Figure 50. Cardan shaft

Intermediate shaft with rubber stop

Shafts with rubber stops effectively prevent vibrations that travel along the shaft to the hull of the boat. This is why they are particularly popular in boats with a metal structure. In the example shaft in figure 51 , there is a rubber joint at one end and a constant speed joint at the other.



Figure 51. Intermediate shaft with rubber stop



CAUTION!

Always ask the manufacturer of the intermediate shaft for installation and operation instructions and follow them carefully.

Installing the intermediate shaft

Note the following when installing the intermediate shaft:

- The shaft must be of such quality that it meets the general shaft-manufacturing standards. A poor-quality shaft may, for example, be balanced incorrectly, causing damage as it rotates.
- The ends of the shaft must be exactly in place against the flange surface before the screws are tightened. Incorrect position leads to wrong joint angle and unbalance. This may cause extensive damage to the system.
- The tightening screws of the intermediate shaft should be tightened a little at a time.



WARNING!

A rotating auxiliary shaft is dangerous. It must be protected with a detachable protector to prevent personal injury.

9. Antifouling



If the boat is going to be used in waterways where the growth and sticking of organisms around the boat's bottom and the propulsion unit is heavy, the propulsion unit can be painted with antifouling paint after installation.

Generally speaking, antifouling paints are based on various soluble substances, such as copper. Because the propulsion unit is made mainly of aluminium, copper forms a highly unfavourable galvanic couple with the propulsion unit. In other words, the aluminium starts to corrode because it functions as an anode.



WARNING!

Painting the propulsion unit with antifouling paint that contains copper will result in heavy corrosion and destruction of the propulsion unit.

Do not use any other antifouling paints for painting the propulsion unit, except those intended for aluminium surfaces!

Instead, a boat bottom made of reinforced plastic can be painted using copper bearing antifouling paint. In this case, leave a 50 mm (2") unpainted area around the propulsion unit in the transom and on the bottom of the boat (figure 52).




Figure 52. Antifouling

- A Unpainted area
- B Painted area



WARNING!

Anodes and their fastening screws must not be painted with antifouling paint.

Appendix 1. Grease recommendations

The grease used for lubricating the propulsion unit bearing must meet the following requirements:

- lithium soap and a thickener with EP additives
- mineral oil as a base oil
- NLGI class 2
- operating temperature range -25 to 130°C (-13-266 °F)
- continuous operating temperature min. 75 °C (167 °F)

Recommended grease brands:

- Würth Multi-Purpose Grease III
- FAG Multi2
- FAG Load 220
- Mobil XHP 222
- Neste Allrex EP2
- Shell Retinax Grease EP2

A grease that has equivalent properties to those mentioned above can also be used for lubrication.

Appendix 2. Oil recommendations

The operating hydraulic system of the reversing deflector and the lubrication of the front bearing are designed to use oil that is specifically intended for automatic transmission systems. The oil must meet the following requirements:

Kinematic viscosity 40°C	33-36 mm ² /s
Kinematic viscosity 100°C	7.1-7.7 mm ² /s
Viscosity index	min. 170
Density 15°C	0.835-0.890 g/cm ³
Pour point	max. -42 °C
Flashpoint	min. 180 °C

Recommended oil brands:

- Mobil ATF 320
- FormulaShell ATF DEXRON III
- Neste ATF-X
- BP Autran DX III

Appendix 3. Tightening torques

Use the tightening torques from the table 2 when tightening the propulsion unit screws. The strength grade of an acid-proof A4-80 screw is equivalent to a class 8.8 screw.

Table 2. Tightening torques of the screws

	Strength grade		
	8.8	10.9	12.9
Thread	Tightening torque (Nm) (*)		
M5	5.5 (4)	8.1 (6)	9.5 (7)
M6	9.6 (7)	14 (10)	16 (12)
M8	23 (17)	34 (25)	40 (30)
M10	46 (34)	67 (49)	79 (58)
M12	79 (58)	115 (85)	135 (100)
M16	145 (107)	215 (159)	250 (184)


(*) The tightening torque in pound-feet (approximate value) is marked in the table in parentheses after the corresponding value in Nm.

A suitable thread locking compound that is good for all purposes is one of medium strength, for example. Loctite 242 or similar.

Appendix 4. Control system hydraulic line

Single installation with an automatic lubrication unit


Green	Low-pressure hose
Red	High-pressure hose
Blue	Grease hose



1	Oil pump	5	Bearing housing
2	Reversing deflector cylinder	6	Bearing housing oil reservoir
3	Oil reservoir	7	Rear bearing housing lubrication channel
4	Automatic lubrication unit	8	Oil cooler

Single installation without an automatic lubrication unit

Green Low-pressure hose
Red High-pressure hose



- | | | | |
|---|------------------------------|---|-------------------------------|
| 1 | Oil pump | 4 | Bearing housing |
| 2 | Reversing deflector cylinder | 5 | Bearing housing oil reservoir |
| 3 | Oil reservoir | 6 | Oil cooler |

Twin installation with automatic lubrication units

In a twin installation that includes automatic lubrication units, the hydraulic connections of both jets are made in the same way as in a single installation that includes an automatic lubrication unit.

Twin installation without automatic lubrication units

In a twin installation that does not include automatic lubrication units, the hydraulic connections of both jets are made in the same way as in a single installation.

Steering cylinder (optional) connections

Yellow Hose to the steering pump




1 Steering cylinder

Available steering nozzle control accessories are listed below


Code	Applicability
H2-041A, H2-041F	Steering kit with power steering, single installation
H2-041A, H2-041F, H2-042, H2-041E	Steering kit with power steering, twin installation
H2-040	Steering nozzle angle indicator


Appendix 5. Connecting rod for multi-installation H2-042



A Control lever

Appendix 6. Control System






- A Reversing deflector's control cable
- B Steering device (cable or hydraulic)
- C Accelerator and gear control cables
- D Connecting rod for double installation


Appendix 7. Lever movement ranges

Control lever



Units in [inches] and millimetres.

Hydraulic cylinder control lever




The length of a full stroke at point A is approx. 64 mm [2.52"].


The length of a full stroke at point B is approx. 46 mm [1.81"].

Appendix 8. Adapter dimensions


Bottom adapter for 5 degree thrust angle



Bottom adapter for 0 degree thrust angle




Transom adapter



A Hole to be cut

Appendix 9. Dimensions of the holes to be cut

The hole to be cut for the bottom adapter **in a welded installation**



The hole to be cut for the bottom adapter **in a bolted installation**

