

Konrad

HIGH OUTPUT PROPULSION SYSTEMS



NOTICE TO INSTALLER

After completing installation this Maintenance Manual should be placed with the Sterndrive for the Owner's future use.

Series 600B

Maintenance Manual

All rights reserved. Reproduction or use, without express permission, of editorial or pictorial content, in any manner, is prohibited. No patent liability is assumed with respect to the use of the information contained herein. While every precaution has been taken in the preparation of this book, the publisher assumes no responsibility for errors or omission. Neither is any liability assumed for damages resulting from use of the information contained herein.

All instructions and diagrams have been checked for accuracy and ease of application; however, success and safety in working with tools depend to a great extent upon individual accuracy, skill and caution. For this reason, the publishers are not able to guarantee the result of any procedure contained herein. Nor can they assume responsibility for any damage to property or injury to persons occasioned from the procedures. Persons engaging in the procedure do so entirely at their own risk.



600B Series Models

MAINTENANCE MANUAL

Version 2.6 for production as of July 1, 2017

**If your drive was produced prior to the above date, please consult an earlier
version of this manual**

Part # 13-657

*Core Content Originated by Randall J. Sofie, October 2007

*Adapted for 600 Series, November 2011

*Adapted for 600B Series, July 2016

TABLE OF CONTENTS

1 - KONRAD 600B SERIES STERNDRIVES

General Information	1
Safety Notices	1
Operation	2
Break-In Procedure	2
Torque Specifications for Fasteners	3
Sterndrive Weights	4
Maintenance Schedule	5
Specified Gear Oil and Lubricants	6
Sterndrive Removal - All Models	7
Sterndrive Installation - All Models	9

2 - KONRAD 600B SERIES GENERAL MAINTENANCE

Sterndrive Gear Lube	
Removing	11
Filling	12
Checking	13
Hydraulic Fluids	
Trim/Lift Pump	14
Propeller and Hardware	
Model 620B	15
Inspection	16
Removal	16
Installation	16
Model 660B	17
Inspection	18
Removal	18
Installation	18
Model 680B	19
Inspection	20
Removal	20
Installation	20

TABLE OF CONTENTS

(continued)

Anodes	21-25
Model 620B	21
Model 660B	22
Model 680B	23
Placement on Sterndrive	24-25
Hoses	26
Bushings	27
Continuity Cables	28

3 - KONRAD 600B SERIES COMPLEX MAINTENANCE

Bellows	29
Universal Joints	30-32
Propeller Shaft Bearing Carrier Seal Replacement	
Model 620B	33-35
Model 660B	36-39
Model 680B	40-43
Electrical Drawings	
Trim/Lift Electrical Drawing (12 Volt)	44-49
Trim/Lift Electrical Drawing (24 Volt)	50-55
Setting the Trim/Lift Sender Switch	56-57
Direct Mount/Tailpiece Alignment	58
Remote Mount Driveshaft Alignment	59-62

Chapter 1 - Sterndrive

General Information

The Konrad 600B Series sterndrives are designed to accommodate engines that generate up to 1200 Nm (885 lb. ft.) of torque at rated / maximum RPM. Maximum torque ratings are drive model and application dependent.

There is a sixteen degree (16°) trim range to optimize vessel performance while underway. There is an additional 30 degrees (30°) of lift range that may only be used in an emergency or when the sterndrive is being serviced or transported.

The Konrad 600B Series sterndrives are designed for applications where the vessel transom angle is 13 degrees (13°). Applications that do not meet this criteria may require extra equipment or modifications, or may not be possible at all. The Konrad 620B and 680B sterndrives are designed to accommodate propellers (aluminum or stainless steel) with a maximum diameter of 20 in (50.8 cm). The Konrad 660B can accommodate propellers (stainless steel) with a maximum diameter of 16 in. (40.6 cm).

Safety Notices

Read and understand all of the safety precautions and warnings before performing any installation or repair. This list contains the general safety precautions and warnings that **MUST** be followed to provide personal safety. This list is only a suggested safety guideline. Working conditions vary greatly, consequently safety measures will vary upon your individual circumstances. **Always use caution.** Make sure the work area surrounding the product is safe. Be aware of hazardous conditions that can exist.

ALWAYS wear protective eyeglasses and protective footwear when working.

DO NOT wear loose-fitting or torn clothing. Remove all jewelry when working.

DO NOT work on anything that is supported **ONLY** by lifting jacks or a hoist. **ALWAYS** use blocks or proper stands to support the product before performing any service work.

TO AVOID PERSONAL INJURY, use a hoist or get assistance when lifting drive components. Make sure all lifting devices such as chains, hooks, or slings are in good condition and are of the correct capacity.

ALWAYS use tools that are in good condition. Make sure you understand how to use them before doing any service work.

ALWAYS use the same fastener part number (or equivalent) when replacing fasteners.


DO NOT use a fastener of lesser quality if replacements are necessary.

ADDITIONAL SAFETY PRECAUTIONS ARE INCLUDED IN THE PROCEDURES WHEN APPLICABLE.

Chapter 1 - Sterndrive *(continued)*

Operation

The engine produces power (clockwise or counterclockwise) that is transmitted through a reversing transmission. Either a coaxial planetary-style reversing transmission or a twin shaft vertically offset standard reversing transmission (with coaxial additions available) are normally used depending upon your application, and vessel design. The transmission is connected via close couple or drive shaft. The power is then transmitted through a series of shafts and gears and then to the propeller(s).

 **WARNING: If a u-joint style drive shaft is used, the drive shaft angle may not exceed one-half degree (.5°). If the angle exceeds one-half degree (.5°), any warranty offered with your application is void.**

Break-In Procedure

Make sure the sterndrive and gimbal carrier are properly filled with gear oil prior to operation.

Any new Konrad sterndrive unit, whether a lower, upper or complete, requires a fifty (50) hour break-in running period. Please use the following guidelines during the first fifty (50) hours to assure optimum performance from your new Konrad sterndrive.

- 1. Avoid full throttle starts.**
- 2. Avoid straining or heavy loading of the sterndrive.**
- 3. To achieve even wear patterns on your new drive gear sets, operate at intermittent throttle levels throughout the entire break-in period.**
- 4. DO NOT exceed seventy-five percent (75%) of full throttle during the first five (5) hours.**
- 5. During the next five (5) hours of the break-in period, operate periodically at full throttle.**
- 6. The sterndrive should be shifted into forward gear a minimum of ten (10) times during the first ten (10) hours with moderate (but not excessive) RPM's after each shift.**
- 7. Change or filter (Using Konrad filter kit 13-389) the gear oil after the fifty (50) hour break-in period is complete.**

***NOTE:** When the initial oil change is done, small metal particles may be found in the break-in oil. Do not be alarmed. This is typical during break-in and will decrease as you run the drive.*

Chapter 1 - Sterndrive *(continued)*

Torque Specifications for Fasteners

Listed below are the torque specifications for those fasteners that have a specified torque value. Securely tighten all other fasteners. Internal drive component torque specifications are stated in the Konrad Series 600B Technical Manual.

Description	Torque Value
Drive Shaft Flange to Transmission Output Flange Shaft Nuts/Bolts (if applicable)	70 lb. ft. (95 Nm)
Transom Assembly / Gimbal Housing Studs to Inner Transom Plate Nuts (6)	50 lb. ft. (67.8 Nm)
Gimbal Ring Center Pin Cover, Hex Head Cap Screw (2)	35 lb. ft. (47.5 Nm)
Gimbal Ring Center Pin Retaining Hex Head Cap Screw (1)	50 lb. ft. (67.8 Nm)
Trim Sender Cover Button Head Cap Screws (2)	13 lb. in. (147 Ncm)
Trim Sender Housing Socket Head Cap Screws (2)	8 lb. ft. (10.8 Nm)
Trim Sender Socket Head Cap Screws (2)	8 lb. ft. (10.8 Nm)
Upper Gear Housing Cap, Socket Head Cap Screws (4)	20 lb. ft. (27 Nm)
Gimbal Carrier Compression Ring Socket Head Cap Screws (4) Tail piece Compression Ring Hex Head Cap Screws (5)	45 lb. ft. (61 Nm) 35 lb. ft. (47.5 Nm)
620B Propeller Nut (1)	80 lb. ft. (109 Nm)
660B Forward Propeller Nut (1)	100 lb. ft. (136 Nm)
660B Aft Propeller Nut (1)	60 lb. ft. (81 Nm)
680B Forward Propeller Nut (1)	100 lb. ft. (136 Nm)
680B Aft Propeller Nut (1)	80 lb. ft. (109 Nm)

Chapter 1 - Sterndrive *(continued)*



600 Series Stern Drive Weight Descriptions

620B Stern Drive

Item Description	620B Weight	
600B Transom assembly (with trim and steering cylinders)	115 lbs	52.2 kg
Trim pump	13 lbs	5.9 kg
Upper housing and Intermediate	151 lbs	68.5 kg
Lower housing assembly	84 lbs	38.1 kg

Total Dry Weight 363 lbs 164.7 kg

Standard 620B Propellers Propeller Weight

3 Blade, Stainless Steel, 18.5" Diameter	24 lbs	10.9 kg
4 Blade, Stainless Steel, 18.5" Diameter	28 lbs	12.7 kg
5 Blade, Stainless Steel, 18.5" Diameter	30 lbs	13.6 kg

660B Stern Drive

Item Description	660B Weight	
600B Transom assembly (with trim and steering cylinders)	115 lbs	52.2 kg
Trim pump	13 lbs	5.9 kg
Upper housing and Intermediate	151 lbs	68.5 kg
Lower housing assembly	67 lbs	30.4 kg

Total Dry Weight 346 lbs 156.9 kg

Standard 660B Propellers Propeller Weight

3 Blade, Stainless Steel, 16" Diameter	14 lbs	6.4 kg
4 Blade, Stainless Steel, 15.25" Diameter	15 lbs	6.8 kg

680B Stern Drive

Item Description	680B Weight	
600B Transom assembly (with trim and steering cylinders)	115 lbs	52.2 kg
Trim pump	13 lbs	5.9 kg
Upper housing and Intermediate	151 lbs	68.5 kg
Lower housing assembly	115 lbs	52.2 kg

Total Dry Weight 394 lbs 178.7 kg

Standard 680B Propellers Propeller Weight

3 Blade, Stainless Steel, FWD, 18.5" Diameter	21 lbs	9.5 kg
4 Blade, Stainless Steel, AFT, 17.25" Diameter	26 lbs	11.8 kg

Chapter 1 - Sterndrive *(continued)*

Maintenance Schedule

USE SERVICE HOURS OR TIME INTERVAL, WHICHEVER OCCURS FIRST!!

<i>All applications will be assigned a Maintenance Schedule "A", "B", or "C", depending on usage characteristics, which must be followed to ensure warranty coverage.</i>			
TASK	Maintenance Service Schedule "A"	Maintenance Service Schedule "B"	Maintenance Service Schedule "C"
Sterndrive Unit Oil - Check Level	Daily	Daily	Daily
Sterndrive Unit Oil - Filter or Change Break in oil	After First 50 Hours	After First 50 Hours	After First 50 Hours
Sterndrive Unit Oil - Change	Every 400 Hours or once a year	Every 600 Hours or once a year	Every 800 Hours or once a year
Power Trim Pump Oil - Check Level	Daily	Daily	Daily
Power Steering Fluid - Check Fluid	Daily	Daily	Daily
Transmission Fluid - Check Level - Change Fluid	Daily See Owners Manual	Daily See Owners Manual	Daily See Owners Manual
Anodes - Inspect for Erosion	Monthly	Monthly	Monthly
Continuity Circuit Check - Check Components for continuity, loose connections, and broken or fraying wires	Every 60 days	Every 60 days	Every 60 days
Hoses - Inspect for cracks, swelling, or signs of deterioration - Check for proper tightness	Every 120 Days	Every 6 months	Once a year
Propeller Shaft - Saltwater Use - Lubricate shaft, check shaft seals for leaking and damage, check propeller hardware torque	Every 60 days	Every 60 days	Every 60 days
Propeller Shaft - Freshwater Use - Lubricate shaft, check shaft seals for leaking and damage, check propeller hardware torque	Every 120 days	Every 120 days	Every 120 days
Universal Joints - Replace	Every 200 hours	Every 400 hours	Every 800 hours
Engine / Tailpiece - Check Alignment	After initial 50 hours then every 200	After initial 50 hours then every 400	After initial 50 hours then every 800
Transom Assembly Bushings - Check for wear at the gimbal ring, trim cylinder, and steering cylinder mounts	Every 200 hours	Every 400 hours	Every 800 hours
Bellows and Clamps - Inspect for proper installation and wear	Every 200 hours	Every 400 hours	Every 800 hours
Transom and Sterndrive Unit - Inspect for corrosion or impact damage, including propeller	Weekly	Weekly	Weekly

Chapter 1 - Sterndrive *(continued)*

Specified Lubricants

Gear / Drive Oil

Konrad 75W90 Full Synthetic Oil		Part number
1 Quart	(.95Liters)	(13-090)
2.5 Gallon	(9.5Liters)	(13-091)
55 Gallon	(208.20 Liters)	(13-092)



Lubricant Capacity 600B Series (standard configuration) **

Complete Sterndrive, 620 model - **approximately** eighteen (18) quarts (17 liters).
Complete Sterndrive, 660 model - **approximately** sixteen (16.5) quarts (15.1 liters).
Complete Sterndrive, 680 model - **approximately** eighteen (18) quarts (17 liters).

**** Oil capacities will vary depending on application configurations, such as spacers, by 1-3 quarts (.95-2.84 liters)**

Make sure the drive is completely filled to the top and purged of air prior to operating.

KVD Transmisson

Mobiltrans HD30 Drive-train oil SAE 30		Part number
1 Gallon	(3.79 Liters)	(13-758)

Fluid capacity

Refer to the owners manual for fluid capacity and how to check the fluid level.

Trim / Lift pump

Dextron III automatic transmission fluid		Part number
1 Quart	(.95 Liters)	(10-585)

Fluid capacity

Trim Pump Reservoir - approximately (1) quart (.95 liters)

Steering system

Dextron III automatic transmission fluid		Part number
1 Quart	(.95 Liters)	(10-585)

Fluid capacity

Capacity will vary depending on the type of steering system used and length of the vessel.


Chapter 1 - Sterndrive *(continued)*

A. Removal All Models


1A. Remove the six (6) M6 X 18mm S.H.C.S. (13-696) and the six (6) washers (12-335) from each side of the upper housing cover. As pictured to the right.



2A. Remove the oil supply hose from the connector on the upper housing assembly, and install cap.



3A. Disconnect the steering cylinder(s) (30-986) from the drive leg by removing the aft cotter pins (13-368), washers (12-352), and the clevis pins (13-341) from the steering cylinder. Repeat the process for the port and starboard sides. Secure the steering cylinders and lines out to the side of the transom.



4A. Rig the Konrad drive for lifting. Secure the sterndrive to the lifting device with a nylon strap or other fastener. An overhead lifting device is the preferred method of lifting the sterndrive, though a lifting cart or forklift may be used as an alternate lifting device.




Chapter 1 - Sterndrive *(continued)*

A. Removal All Models

5A. Loosen the aft bellows clamp, (10-336) and push the bellows (10-230) forward off of the drive.



6A. Remove the two (2) H.H.C.S. (13-310) from the lower pivot pin cover (13-320) and remove cover.



7A. Remove the pivot pin retaining H.H.C.S. (13-560) from the front of the intermediate section of the drive. Slide the pivot pin (13-561) downward and remove from the gimbal ring.



8A. Remove the continuity cable (30-907) from the intermediate housing, and slide the drive aft, away from the gimbal ring and housing.



Chapter 1 - Sterndrive

B. Installation All Models

1B. Remove the two H.H.C.S. (12-378) from the top pivot pin cover / rudder indicator plate cover. (13-574).

Be careful not to rotate the sensor shaft.



2B. Pull the alignment pin (10-494) out of the recess in the input yoke and grease the input yoke splines and the alignment pin. Insert the alignment pin 1/4 of the way back into the yoke.



3B. Slide the drive toward the transom assembly, aligning the center of the gimbal ring with the drive's intermediate pivot point making sure the gimbal ring bushings are in place. Carefully slide the alignment pin and end yoke into the bellows and into the splines of the drive shaft carrier or transmission tailpiece. Reinstall the u-joint bellows onto the drive and tighten the clamp.



4B. Reinstall the center pivot pin (13-561) into the lower gimbal ring and upward through the drives intermediate section, align the hole in the pin for the retaining bolt by using the slot on the bottom of the pin. Secure the pin by reinstalling the retaining H.H.C.S. (13-560) Apply red *Loctite* 263 to the threads of the retaining H.H.C.S. and tighten to 50 lb. ft. (67.8 Nm).



Chapter 1 - Sterndrive (continued)

B. Installation All Models

5B. Reinstall the top pivot pin cover by applying red *Loctite 263* to the H.H.C.S. (12-378).

Reinstall the bottom pivot pin cover by applying red *Loctite 263* to the H.H.C.S. (13-310).

Tighten to 35 lb.ft. (47.5 Nm).

NOTE: *When reinstalling the top cover with a rudder indicator, be sure to align the sensor pin with the slot on top of the drive pivot pin.*



6B. Reattach the steering cylinders to the drive leg by installing the aft clevis pins (13-341), washers (12-352), and the cotter pins (13-368) to the steering cylinder. Repeat the process for the port and starboard sides.

NOTE: *Make sure the steering cylinder bushings (13-319) are installed on each side of the rod end prior to installing steering cylinders into the drive steering tabs.*



7B. Remove the lifting ring and install the plug (10-010) and gasket (10-285). Remove the cap (13-251) on the oil supply line fitting, and reinstall the oil supply line (31-130) from the transom using blue *Loctite 243* on the fitting, and tighten the fitting.

Secure the continuity cable (30-907) that was previously removed in step 8A by installing the self tapping screw (10-479).



8B. Reinstall the cover onto the upper housing. Install blue *Loctite 243* onto the S.H.C.S. before placing them through the flat washers and hand tightening.

9B Install the six (6) M6 X 18mm S.H.C.S. (13-696) and the six (6) washers (12-335) into each side of the upper housing cover.



Chapter 2 - General Maintenance *(continued)*

Removing Lubricant

1. Trim drive unit to full “OUT” or “UP” position.

****NOTE: Units produced 1 May 2016 SN 9015 and later, All six (6) S.H.C.S. attaching the cover are the same M6 X 18mm (13-696) and washer (12-335)**

2. Remove the six (6) M6 X 18mm S.H.C.S. (13-696) and the six (6) washers (12-335) from each side of the upper housing cover. As pictured to the right.

Remove the upper housing cover.

Note: either of the following methods for venting will work.





- 3a. Remove the top vent plug (10-010) located on the top cap (13-421).

- 3b. Remove the S.H.C.S. from the top cap and remove the top cap from the upper housing.

4. Remove the bottom fill/drain plug (10-155). Allow lubricant to drain completely.

5. Trim drive unit to full “In” or “Down” position (with anti-ventilation plate level) to complete draining process.

6. Refer to previous page for filling procedure and required lubricant.




NOTE: Discharge of oil or oily waste into or upon the water is a direct violation of today's laws. Dispose of or recycle these substances properly.

Chapter 2 - General Maintenance

Filling

Pour Method Is Recommended:


1. Remove the six (6) M6 X 18mm S.H.C.S. (13-696) and the six (6) washers (12-335) from each side of the upper housing cover. As pictured to the right.



2. Remove the top cap (13-421) of the sterndrive by removing the socket head cap screws (12-951).

3. Pour in gear oil until it reaches just below the top cap.

4. Wait fifteen (15) minutes. Rotate the propeller five or six (5-6) times in both directions during those fifteen (15) minutes.




5. Repeat steps 3 and 4.

6. Replace the top cap (13-421) and torque the S.H.C.S. (12-951) to 80 lb in (9 Nm).

NOTE: Make sure top cover o-ring (12-759) is greased and properly seated.

7. Reinstall the upper housing cover (13-333 or 13-587) onto the drive housing. Apply blue Loctite 243 to the S.H.C.S. and secure the cover onto the drive.



Chapter 2 - General Maintenance *(continued)*

Checking Lubricant Level

NOTE: The sterndrive oil level is checked at the remote oil reservoir. There is only one (1) reservoir used per drive. The four (4) quart (3.79 l) reservoir assembly has a part number of 30-992.



30-992
Reservoir Assembly
4 Quart

CAUTION: If the lubricant in the reservoir is milky brown or the lubricant is not level with the “fill line”, there may be a leak in the drive unit. Before further use, the area where the leak occurs should be identified and corrected. Then refill the unit with new lubricant.

IMPORTANT: Always check oil level when the drive is cool and engine is shut down. Oil level in the reservoir will rise and fall during drive operation.

If the lubricant reservoir is empty, **DO NOT** attempt to fill drive unit through reservoir, as air may be trapped in the drive unit and the sterndrive could be damaged from lack of lubrication.

After cause for low lubricant has been found and corrected, refill drive unit with lubricant, as outlined under “Filling” on the previous pages.

Chapter 2 - General Maintenance *(continued)*

Hydraulic Fluids

Filling

1. Remove cap (10-689) from the trim/lift pump reservoir.
2. Fill reservoir with specified fluid to indication line (maximum level).

IMPORTANT: Check fluid level with sterndrive unit in the full down position.

Bleeding

1. Fill the trim/lift pump reservoir to appropriate level (if not already done).
2. Remove the down line from trim pump and place it in a container to catch any purged fluid. Hold one (1) finger over the down line port of the trim/lift pump to prevent the intake of air. Trim the drive all the way up using the toggle switch on the side of the trim pump cover.

NOTE: Fluid may need to be added if the reservoir bottle level goes below the minimum.

3. With the drive in the “UP” position, attach the down line to the trim/lift pump.
4. Cycle the drive all the way to the “DOWN” position and then all the way to the “UP” position. Repeat this step three or four (3-4) times to purge any remaining air out of the system.

Chapter 2 - General Maintenance *(continued)*


Propeller and Hardware

Model 620B Description and Parts Breakdown



WARNING: Remote Control must be in NEUTRAL, the engine turned off and ignition key removed from switch before removing and/or installing propeller.

Model 620B



Individual Components

	Description	Quantity	Part Number
A	Prop Shaft (L) OR	1	10-360
	Prop Shaft (R)	1	10-363
B	Forward Thrust Hub	1	10-292
C	Propeller	1	variable
D	Splined Washer	1	10-293
E	Tab Washer	1	10-295
F	Propeller Nut	1	10-296

Chapter 2 - General Maintenance *(continued)*

When a stainless steel propeller is used, care must be taken to maintain good continuity between the prop and the prop shaft to prevent corrosion. Periodic removal of the propeller, a thorough cleaning of its hub, the prop shaft and all mounting components, and lubrication of the shaft with **marine grade grease** (or equivalent) will help maintain good continuity and prevent corrosion. A continuity washer can be installed between the propeller and the splined washer on all models to help maintain continuity.

Inspection

1. Check propeller shaft nut for correct torque, 80 lb. ft. (108 Nm).
2. Check propeller blades for any indication of damage.
3. Check tab washer - verify at least two (2) tabs are bent over.

Removal

1. Unbend retaining washer tabs using Konrad Tool TO-063.
2. Place a block of wood between the propeller and cavitation plate.
3. Remove propeller nut.
4. Remove additional propeller hardware (see diagram on previous page).
5. Slide propeller off of splined shaft.
6. Remove thrust washer.

Installation

1. Grease and slide thrust washer onto propeller shaft.

***NOTE:** Tapered end of thrust washer must be towards the drive.*

2. Grease splined area and the threads of the propeller shaft.
3. Place the propeller on the propeller shaft followed by the appropriate hardware. (see diagram previous page).
4. Torque the propeller nut, using a 1 7/16" socket tool, to 80 lb. ft. (108 Nm). When approaching 80 lb. ft. (108 Nm), make sure that the tabs on the tabbed retaining washer (at least 2 out of 6) line up with the grooves in the splined washer/hub.

***NOTE:** A block of wood can be placed between the propeller and the lower drive housing to prevent the propeller from spinning, while torquing the propeller nut.*


5. Bend over the tabs using appropriate tools.

Chapter 2 - General Maintenance *(continued)*

Propeller and Hardware

Model 660B Description and Parts Breakdown

 **WARNING:** Remote Control must be in NEUTRAL, the engine turned off and ignition key removed from switch before removing and/or installing propeller.



Individual Components

	Description	Quantity	Part Number
A	Forward Prop Shaft	1	12-502
B	Forward Thrust Hub	1	12-509
C	Forward Propeller	1	variable
D	Forward Prop Nut	1	12-506
E	Aft Prop Shaft	1	12-503
F	Aft Thrust Hub	1	12-508
G	Aft Propeller	1	variable
H	Aft Prop Nut	1	12-529

Chapter 2 - General Maintenance *(continued)*

When a stainless steel propeller is used, care must be taken to maintain good continuity between the prop and the prop shaft to prevent corrosion. Periodic removal of the propeller, a thorough cleaning of its hub, the prop shaft and all mounting components, and lubrication of the shaft with **marine grade grease** (or equivalent) will help maintain good continuity and prevent corrosion. A continuity washer can be installed between the propeller and the splined washer on all models to help maintain continuity.

Inspection

1. Check Aft propeller shaft nut for correct torque, 60 lb. ft. (81 Nm).
2. Check propeller blades for any indication of damage.
3. After removal of aft propeller, check forward propeller shaft nut for correct torque, 100 lb. ft. (136 Nm).

Removal

1. Once procedure below is completed for the aft propeller, repeat steps to remove the forward propeller.
2. Place a block of wood between the propeller and cavitation plate.
3. Remove aft propeller nut with $1\frac{7}{16}$ " socket and breaker bar (for forward propeller, use hex wrench TO-121).
4. Remove additional propeller hardware (see diagram on previous page).
5. Slide propeller off of splined shaft.

Installation

FORWARD Propeller:

- 1a. Slide forward thrust hub onto forward prop shaft so the tapers meet. Some grease can be used on tapers to hold in place.
- 2a. Grease splined area and the threads of the forward propeller shaft.
- 3a. Place the forward propeller on the propeller shaft until it seats against thrust hub.
- 4a. Torque the forward propeller nut to 100 lb.ft. (136 Nm) using hex wrench TO-121.

AFT Propeller:

- 1b. Slide aft thrust hub onto aft prop shaft so the tapers meet. Some grease can be used on tapers to hold in place.
- 2b. Grease splined area and the threads of the aft propeller shaft.
- 3b. Place the aft propeller on the propeller shaft until it seats against thrust hub.
- 4b. Torque the aft propeller nut to 60 lb.ft. (81 Nm) using $1\frac{7}{16}$ " socket wrench.

Chapter 2 - General Maintenance *(continued)*


Propeller and Hardware

Model 680B Description and Parts Breakdown



WARNING: Remote Control must be in NEUTRAL, the engine turned off and ignition key removed from switch before removing and/or installing propeller.

Model 680B



Individual Components

	Description	Quantity	Part Number
A	Forward Prop Shaft	1	12-705
B	Forward Thrust Hub	1	12-707
C	Forward Propeller	1	variable
D	Forward Prop Nut	1	12-710
E	Aft Prop Shaft	1	12-704
F	Aft Thrust Hub	1	12-708
G	Aft Propeller	1	variable
H	Aft Prop Nut	1	12-716

Chapter 2 - General Maintenance *(continued)*

When a stainless steel propeller is used, care must be taken to maintain good continuity between the prop and the prop shaft to prevent corrosion. Periodic removal of the propeller, a thorough cleaning of its hub, the prop shaft and all mounting components, and lubrication of the shaft with **marine grade grease** (or equivalent) will help maintain good continuity and prevent corrosion. A continuity washer can be installed between the propeller and the splined washer on all models to help maintain continuity.

Inspection

1. Check Aft propeller shaft nut for correct torque, 80 lb. ft. (108 Nm).
2. Check propeller blades for any indication of damage.
3. After removal of aft propeller, check forward propeller shaft nut for correct torque, 100 lb. ft. (136 Nm).

Removal

1. Once procedure below is completed for the aft propeller, repeat steps to remove the forward propeller.
2. Place a block of wood between the propeller and cavitation plate.
3. Remove aft propeller nut with $1\frac{13}{16}$ " socket and breaker bar (for forward propeller, use hex wrench TO-129).
4. Remove additional propeller hardware (see diagram on previous page).
5. Slide propeller off of splined shaft.

Installation

FORWARD Propeller:

- 1a. Slide forward thrust hub onto forward prop shaft so the tapers meet. Some grease can be used on tapers to hold in place.
- 2a. Grease splined area and the threads of the forward propeller shaft.
- 3a. Place the forward propeller on the propeller shaft until it seats against thrust hub.
- 4a. Torque the forward propeller nut to 100 lb.ft. (136 Nm) using hex wrench TO-129.

AFT Propeller:

- 1b. Slide aft thrust hub onto aft prop shaft so the tapers meet. Some grease can be used on tapers to hold in place.
- 2b. Grease splined area and the threads of the aft propeller shaft.
- 3b. Place the aft propeller on the propeller shaft until it seats against thrust hub.
- 4b. Torque the aft propeller nut to 80 lb.ft. (108 Nm) using $1\frac{13}{16}$ " socket wrench.


Chapter 2 - General Maintenance *(continued)*

Anodes

Description and Parts Breakdown

Model 620B

Models built prior to 1 April 2017 don't use item 5 or 6.



Individual Components - 620B

Item #	Description	Quantity	Part #	Part #
1	Anode, Cylinder	2	-	13-749
2	Screw	4	13-750	-
3	Plate, Inhibitor	2	-	12-475
4	Anode, 600 Upper	1	-	13-640
5	Plate, Inhibitor	2	-	12-473
6	F.H.C.S.	4	10-461	-


Complete Anode Kit for 620B as shown above is Part # 31-099
All Anode Kits are created with Aluminum Anodes

Chapter 2 - General Maintenance *(continued)*

Anodes

Description and Parts Breakdown

Model 660B



Individual Components - 660B

Item #	Description	Quantity	Part #	Part #
1	Anode, Cylinder	2	-	13-749
2	Screw	4	13-750	-
3	Anode, 600 Upper	1	-	13-640
4	Anode	1	-	13-666

Complete Assembly Kit for 660B Part # 31-098
All Anode Kits are created with Aluminum Anodes


Chapter 2 - General Maintenance *(continued)*

Anodes

Description and Parts Breakdown

For Model 680B built after 1 June 2016

For Models built prior to 1 June 2016 don't use item 5 or 6.



Individual Components - 680B


Item #	Description	Quantity	Part #	Part #
1	Anode, Cylinder	2	-	13-749
2	Screw	4	13-750	-
3	Plate, Inhibitor	2	-	12-475
4	Anode, 600 Upper	1	-	13-640
5	Plate, Inhibitor	2	-	12-473
6	F.H.C.S.	4	10-461	-

Complete Anode Kit for 680B as shown above is Part # 31-099
All Anode Kits are created with Aluminum Anodes

Chapter 2 - General Maintenance *(continued)*

Anodes

Placement on Sterndrive



Chapter 2 - General Maintenance *(continued)*

Model 620B - Placement of Anodes on Sterndrive

Item #	Description	Quantity	Part #
1	Plate Inhibitor after 1 April 2017	2	12-473
2	Plate, Inhibitor	2	12-475
3	Anode, 600 Upper	1	13-640
5	Steering Cylinder Anode	2	13-749

Model 660B - Placement of Anodes on Sterndrive

Item #	Description	Quantity	Part #
3	Anode, 600 Upper	1	13-640
4	Anode	1	13-666
5	Steering Cylinder Anode	2	13-749


Model 680B - Placement of Anodes on Sterndrive

Item #	Description	Quantity	Part #
1	Plate, Inhibitor after 1 June 2016	2 (if applicable)	12-473
2	Plate, Inhibitor	2	12-475
3	Anode, 600 Upper	1	13-640
5	Steering Cylinder Anode	2	13-749

Chapter 2 - General Maintenance *(continued)*


Hoses

Trim Cylinder - External - 30-995



4 per drive

Steering Cylinder - External - 30-993




2 per cylinder

Overflow Hose - 31-130




1 per drive

Trim Pump to Transom




6 per drive

Oil Reservoir to Transom - Direct Mount



Oil Reservoir to Transom - Remote Mount




13-130 - 1 per drive for Direct and Remote Mount - 10-705 - 2 Per drive Remote Mount

Chapter 2 - General Maintenance *(continued)*


Bushings

Steering Cylinder - 13-319




2 per cylinder

Steering Cylinder - 13-342




2 per cylinder

Trim Cylinder - 13-319



2 per cylinder

Trim Cylinder - 13-360




1 per cylinder

Gimbal Ring - 13-314



2 per drive


Gimbal Pin - 13-322 and 13-324



2 of each per drive


Chapter 2 - General Maintenance *(continued)*

Complete Continuity Kit for 600B Series Part # 31-034




Individual Components

Item #	Description	Quantity	Part #
1	Screw, Self Tapping	3	10-479
2	Cable, Continuity	1	30-907
3	Cable, Continuity	1	30-905
4	Cable, Continuity	1	31-094



2




3

Chapter 3 - Complex Maintenance

Bellows

Description and Parts Breakdown



Individual Components

Description	Quantity	Part #
Bellows	1	10-230
Hose clamp	2	10-336

Inspection

Look for any cracks, holes, tears or a broken seal.

Look for large amount of corrosion on the surface of material or excessive wear.

Removal & Installation - Bellows

NOTE: Sterndrive must be removed for removal and installation of bellows.

Remove U-joint bellows from gimbal housing by loosening the two (2) hose clamps (10-336).

Position ground clips on bellows.

Position u-joint bellows with “TOP” mark facing upwards and install u-joint bellows on gimbal housing flange and position clamp. Torque to 30-40 lb. in. (3.4 - 4.5 Nm).


NOTE: When ordering the bellows (10-230), the two (2) hose clamps (10-336) are included.

IMPORTANT: Be sure that the bead on the inner mating surface of bellows is positioned in the groove on the gimbal-housing flange.

Chapter 3 - Complex Maintenance *(continued)*

Universal Joints

Description and Parts Breakdown



Complete U-Joint Assembly 30-831

Individual Component

Item No.	Description	Quantity	Part #
1	Yoke, End	1	12-766
2	O-Ring	1	12-586
3	Washer, Tab	1	12-768
4	Cap Screw	1	12-840
5	Cross & Bearing	2	10-373
6	Ring, Snap	8	10-518
7	Shaft, End Yoke	1	10-365
8	H-Yoke	1	10-366
9	O-Ring	1	10-493
10	Pin, Engagement	1	10-494

Chapter 3 - Complex Maintenance *(continued)*

Maintenance U-Joint

NOTE: Sterndrive must be removed for inspection, removal and installation of the u-joint assembly.

Inspection

Inspection Before Disassembly

1. U-joint cross and bearings should be inspected for wear and possible replacement following the maintenance schedule for your application. Some applications may require shorter intervals.
2. Check cross and bearing for roughness and excessive side-to-side play.
3. Check splines on coupling end yoke for wear.
4. If troubleshooting a u-joint knocking condition, inspect for evidence of interference with bearing caps hitting center socket.

Cleaning and Inspection

1. Clean all parts **except the bearing** in fresh solvent. Blow dry with compressed air.

IMPORTANT: DO NOT clean bearing with solvent, as this will wash away the lubricant that retains needle bearings.

2. Inspect crosses for the following:
 - Bearing surfaces - for pitting, scratches and grooves
 - Ends - for galling
 - Seal - for cracks or other signs of deterioration
3. Inspect coupling and gear end of u-joint - for spline wear.
4. Clean all corrosion from the coupling.
5. Replace coupling yoke if splines are partially corroded away.

NOTE: If wear or corrosion is found in the u-joint assembly, contact Konrad for new parts and/or service.

Chapter 3 - Complex Maintenance *(continued)*

Removal

Universal Joint Shaft Assembly

U-joint cross and bearings should be replaced in accordance with your assigned Maintenance Schedule A, B, or C, at two hundred (200) to eight hundred (800) hours (or before if necessary depending on usage). The u-joint assembly requires two (2) cross and bearings, (10-373).

CAUTION: New snap rings should be installed whenever new cross and bearing kits are installed. The 600 sterndrive utilizes a **special snap ring** (10-518), different than many of those found on other sterndrives or with after market cross and bearing sets. It is required that only these snap rings be used.

1. Remove external snap rings.
2. Remove bearing cup.
3. Remove second bearing.
4. Remove yoke.

Installation

Universal Joint Shaft Reassembly

Lube Specifications

Use only non-lithium soap base or equivalent E.P. grease with an operating temperature of three hundred twenty-five degrees Fahrenheit (+325° F) (163° C) to minus ten degrees Fahrenheit (-10° F) (-23° C), meeting N.L.G.I. grade one (1) or two (2) specifications or DIN51. **The use of any other lubricant will decrease the life of the bearings.**


1. Press bearing caps into yoke and onto cross. If a press is unavailable, use a large c-clamp.
2. Install external snap rings (10-518)
3. Repeat same procedure for other bearing caps.
4. Lubricate cross and bearings with a liberal amount of above specified lube.

NOTE: *When u-joint assembly is completely removed from the upper housing of the sterndrive for u-joint maintenance, it is recommended that a new front seal (12-018) be used when reinstallation occurs.*

Chapter 3 - Complex Maintenance *(continued)*

Propeller Shaft Bearing Carrier Seal Replacement

Model 620B





Individual Components - 620B

Item #	Description	Quantity	Part #
1	Cover Nut	1	12-783
2	Washer	1	12-784
3	Key	1	10-017
4	O-Ring	1	12-796
5	Ring, Load	1	12-798
6	Carrier, Bearing	1	12-797
7	Seal	1	13-641
8	Bearing, Roller	1	10-394
9	Shaft, Prop - RH - OR Shaft, Prop - LH	1	10-363 OR 10-360
10	Seal	1	13-641

Chapter 3 - Complex Maintenance *(continued)*

Model 620B Prop Shaft Parts



Chapter 3 - Complex Maintenance *(continued)*

Removal

1. Bend down tab on tab washer (12-784).
2. Remove cover nut (10-783) from lower housing using tool TO-148.
3. Remove tab washer (12-784).
4. Remove bearing carrier (12-797) using TO-036, remove o-ring (12-796), thrust washer (12-799), and load ring (12-798).

NOTE: If bearing carrier cannot be removed, try to heat up lower housing.

NOTE: Recover key (10-017).

5. Remove propeller shaft (10-360 Left Hand) or (10-363 Right Hand).

Rebuilding

1. Remove both (13-641) seals using a seal driver or punch.
2. Remove bearing (10-394) using a bearing driver or punch.
3. Clean carrier unit (12-797) thoroughly.
4. Press new bearing (10-394) into carrier unit using tool TO-019.
5. Apply red *Loctite* 263 to outside of first seal (13-641) and grease inner seal surface. Press into carrier unit with raised numbers printed on the seal facing up using the long side of tool TO-030 with the thick shoulder.

Apply red *Loctite* 263 to outside of second seal (13-641) and grease inner seal surface. Press into carrier unit with the raised numbers printed on the seal facing downward using the opposite, shorter side of tool TO-030 with the thin shoulder. Fill the space in between the two seals with grease.


Installation

1. Install a new crush ring (12-798). The old one may not be reused.
2. Install thrust washer (12-799), propeller shaft (10-360 Left Hand) or (10-363 Right Hand) and key (10-017) into housing.
3. Install bearing carrier (12-797)
4. Bend tabs up thirty degrees (30°) on tab washer (12-784) and insert into housing.
5. Lubricate cover nut (12-783) with 90w oil and install into housing. Tighten until 25-30 lb ft (34-41 Nm) of rolling torque is achieved on the propeller shaft.
6. Bend tab over on tab washer (12-784) into open slot on cover nut (12-783).
7. Install tool TO-103 and pressurize drive to 10-12 psi. Let set for 10-15 minutes and check gauge for pressure loss. If pressure loss is noted, repressurize drive and spray with soapy water and check for leaks, repair as needed.

Chapter 3 - Complex Maintenance *(continued)*

Propeller Shaft Bearing Carrier Seal Replacement

Model 660B




Individual Components - 660B

Item #	Description	Quantity	Part #
1	Shim Set	1	12-515
2	Bearing Set	1	12-521
3	Shaft, Prop, Fwd	1	12-502
4	Needle Bearing, Aft	1	12-520
5	Seal, Inner	1	12-525
6	Seal, Fishline Cutter	1	12-517
7	Nut, Retaining, Fwd	1	12-513
8	O-Ring, TP Carrier	1	12-527
9	Carrier, TP	1	12-510
10	Needle Bearing, Fwd	1	12-522
11	Seal, Inner Fwd	1	12-526
12	Seal, Fishline Cutter	1	12-518
13	Nut, Retaining, Aft	1	12-954
14	Washer, Tab	1	12-838
15	Cap Screw	4	12-839

Chapter 3 - Complex Maintenance *(continued)*

Model 660B Prop Shaft Parts



Chapter 3 - Complex Maintenance *(continued)*

Removal

1. Remove four (4) (12-839) S.H.C.S. using a standard allen socket wrench.
2. Using a needle nose pliers, remove tab washer (12-838).
3. Remove outer retaining nut (12-954) from lower housing using tool TO-142. Turn counter clockwise to loosen. Remove carrier (12-510) from lower housing using tool TO-151.
4. Remove retaining nut (12-513) from lower housing using tool TO-119. Turn counterclockwise to loosen.
5. Remove forward propeller shaft assembly (12-502) by pulling straight out and over the aft propeller shaft. The race of bearing (12-521) from the lower housing should pull out with this assembly.

NOTE: *The gear assembly and thrust cap will come out with the propeller shaft as they are assembled to the shaft.*

6. Recover shims (12-515) from lower housing and/or stuck to bearing race.

Rebuilding

1. Remove both seals (12-517) and (12-525) from propeller shaft assembly (12-502) using slide hammer TO-028.

NOTE: *Be careful not to damage surface of thrust cap on the opposite end of the propeller shaft. Protect with some sort of cloth.*

2. Clean propeller shaft assembly (12-502) thoroughly.
3. Apply red *Loctite* 263 to outside of first seal (12-525) and grease inner seal surface. Press into propeller shaft using long end of tool TO-116. Apply red *Loctite* 263 to outside of second seal (12-517) and grease inner seal surface. Press into propeller shaft using opposite side of tool TO-116. Fill space in between two seals with grease.
4. Remove both seals (12-518) and (12-526) from carrier (12-510) using punch or slide hammer TO-028.
5. Remove o-ring (12-527) from carrier (12-510).
6. Clean carrier unit (12-510) thoroughly.
7. Place new o-ring (12-527) in groove on carrier and grease o-ring.
8. Apply red *Loctite* 263 to outside of first seal (12-526) and grease inner seal surface. Press into carrier unit using long end of tool TO-117. Apply red *Loctite* 263 to outside of second seal (12-518) and grease inner seal surface. Press into carrier unit using opposite side of tool TO-117. Fill space in between two seals with grease.

Chapter 3 - Complex Maintenance *(continued)*

Installation

1. Install forward propeller shaft assembly (12-502) by sliding it over aft propeller shaft.
2. Install shims (12-515) into lower housing. If shims look damaged or were damaged during disassembly, replace with the same thickness as came out.
3. Slide race of bearing (12-521) into lower housing until it seats against bearing on gear assembly. May need to guide race down with retaining nut (12-513) in next step.

NOTE: *This should not be a press fit.*

4. Lubricate outer diameter of retaining nut (12-513) with 90W oil and install into lower housing.
*Torque nut to 200 lb. ft. (271 Nm) using spanner wrench (TO-119).

***NOTE:** *Please refer to the appropriate table in the Konrad Technical Manual to see what reading to set torque wrench to achieve 200 lb. ft. (271 Nm) of torque.*

5. Check rolling torque of lower unit as described in the Konrad Technical Manual.
6. Slide carrier (12-510) into lower housing, be sure to align dowel pins on carrier to retaining nut (12-513). Grease outer retaining nut with Teflon/anti-seize lubricant (12-954) tighten retaining nut using tool TO-142 and **Torque to 100 ft. lb.
7. Install tab washer. Look to see if threaded hole lines up to hole in tab washer.
If bolt lines up, put *Loctite* on threads and install S.H.C.S.
If bolt holes don't line up, remove tab washer and tighten carrier until holes line up.


****NOTE:** *Please refer to the appropriate table in the Konrad Technical Manual to see what reading to set torque wrench to achieve 100 lb. ft. (136 Nm) of torque.*

8. Install tool TO-103 and pressurize drive to 10-12 psi. Let set for 10-15 minutes and check gauge for pressure loss. If pressure loss is noted, repressurize drive and spray with soapy water and check for leaks, repair as needed.

Chapter 3 - Complex Maintenance *(continued)*

Propeller Shaft Bearing Carrier Seal Replacement

Model 680B





Individual Components - 680B

Item #	Description	Quantity	Part #
1	Prop Shaft, Fwd	1	12-705
2	Carrier, Bearing	1	12-706
3	Shim Set, Aft Bearing	1	12-714
4	Bearing	1	12-721
5	O-Ring	1	12-722
6	Roller Bearing, Fwd	1	12-723
7	Seal, Inner, Fwd Prop Shaft	1	13-547
8	Seal Outer, Fwd Prop Shaft	1	13-547
9	Cover, Nut, Fwd	1	10-242
10	Washer, Tab	1	12-925
11	Cover, Nut, Aft	1	12-955
12	Cap Screw	4	12-952
13	Seal, Inner, Aft Prop Shaft	1	13-641
14	Seal, Outer, Aft Prop Shaft	1	13-641

Chapter 3 - Complex Maintenance *(continued)*

Model 680B Prop Shaft Parts



Chapter 3 - Complex Maintenance *(continued)*

Removal

1. Remove (4) S.H.C.S. (12-952) from tab washer (12-925) and remove tab washer using needle nose pliers.
2. Remove outer retaining nut (12-955) from lower housing using tool (TO-149).
3. Remove bearing carrier (12-706) using carrier remover (TO-171).
4. Remove inner retaining nut (10-242) from lower housing using inner nut wrench (TO-150).
5. Remove forward propeller shaft assembly (12-705) by pulling straight out and over the aft propeller shaft. The race of bearing (12-721) from the lower housing should pull out with this assembly.

***NOTE:** The gear assembly and thrust cap will come out with the propeller shaft, as they are assembled to the shaft.*

6. Recover shims (12-714) from lower housing and/or stuck to the bearing race.

Rebuilding

1. Remove both (13-641) seals from propeller shaft assembly (12-705) using slide hammer TO-028.

***NOTE:** Be careful not to damage the surface of thrust cap on the opposite end of end of the propeller shaft. Protect with some sort of cloth.*

2. Clean propeller shaft assembly (12-705) thoroughly.
3. Apply red *Loctite* 263 to outside of first seal (13-641) and grease inner seal surface. Press into propeller shaft with the raised numbers printed on the seal facing up using the long end of tool TO-030 with the thick shoulder. Apply red *Loctite* 263 to outside of second seal (13-641) and grease inner seal surface. Press into propeller shaft with the raised numbers printed on the seal facing down using opposite end of tool TO-030 with thin shoulder. Pack space in between the two seals with grease.
4. Remove both (13-547) seals from carrier (12-706) using punch or slide hammer TO-028.
5. Remove o-ring (12-722) from carrier (12-706).
6. Clean carrier (12-706) thoroughly.
7. Apply red *Loctite* 263 to outside of first seal (13-547) and grease inner seal surface. Press into carrier unit with the numbers printed on the seal facing up using the long end of the tool TO-131 with the thick shoulder. Apply red *Loctite* 263 to outside of second seal (13-547) and grease inner seal surface. Press into carrier unit with the numbers printed on the seal facing down using opposite thin end of tool TO-131 with the thin shoulder. Pack space in between the two seals with grease.

Chapter 3 - Complex Maintenance *(continued)*

Installation

1. Install forward propeller shaft assembly (12-705) by sliding it over aft propeller shaft.
2. Install shims (12-714) into lower housing. IF shims look damaged or were damage during disassembly, replace with the same thickness as came out.
3. Slide race of bearing (12-721) into lower housing until it seats against bearing on gear assembly. May need to guide race down with retaining nut (10-242) in next step.

NOTE: *This race should not be a press fit into lower housing.*

4. Lubricate threads with 90W oil and install retaining nut (10-242) into lower housing. *Torque nut to 200 lb. ft. (271 Nm) using spanner wrench (TO-150)

***NOTE:** *Please refer to the appropriate table in the Konrad Technical Manual to see what reading to set torque wrench to achieve 200 lb. ft. (271 Nm) of torque.*


5. Check rolling torque of lower unit as described in the Konrad Technical Manual.
6. Grease outer diameter of carrier and install carrier unit (12-706) into lower housing, aligning dowel pins on carrier to retaining nut (10-242).
7. Lubricate threads on outer retaining nut (12-955) with a Teflon/anti-seize lube and install using tool TO-149. **Torque nut to 100 lb. ft. (136 Nm) using tool (TO-149)

****NOTE:** *Please refer to the appropriate table in the Konrad Technical Manual to see what reading to set torque wrench to achieve 100 lb. ft. (136 Nm) of torque.*

8. Install tab washer (12-925) into lower housing. If holes don't align, tab washer must be removed and retaining nut must be tightened until both parts have aligning holes.
9. Install blue Loctite on the four S.H.C.S. (12-925) and install into tab washer and outer retaining nut. Torque to 28 lb. in. (3.2 Nm)
10. Install tool TO-103 and pressurize drive to 10-12 psi. Let set for 10-15 minutes and check gauge for pressure loss. If pressure loss is noted, repressurize drive and spray with soapy water and check for leaks, repair as needed.


Chapter 3 - Complex Maintenance (continued)

Trim/Lift Electrical Drawing (12 Volt) single drive, single helm




Chapter 3 - Complex Maintenance *(continued)*

Trim / Lift Electrical Drawing (12 Volt) single drive, dual helm




Chapter 3 - Complex Maintenance (continued)

Trim / Lift Electrical Drawing (12 Volt) twin drive, single helm



Chapter 3 - Complex Maintenance *(continued)*


Trim / Lift Electrical Drawing (12 Volt) twin drive, dual helm



Chapter 3 - Complex Maintenance (continued)

Trim / Lift Electrical Drawing (12 Volt) triple drive, single helm

KONRAD MARINE INC.
TRIM SYSTEM ELECTRICAL
DRAWING (12 VOLT)
600B TRIPLE




DRAWING BY A.G.
AUGUST 2015

Chapter 3 - Complex Maintenance (continued)

Trim / Lift Electrical Drawing (12 Volt) triple drive, dual helm

KONRAD MARINE INC.
TRIM SYSTEM ELECTRICAL
DRAWING (12 VOLT)
600B TRIPLE DUAL HELM




NOTES FOR HARNESS 31-004:
1) ALL THROTTLE CONTROL WIRES ARE INCLUDED; HOWEVER, NOT ALL APPLICATIONS WILL UTILIZE ANY OR ALL OF THE WIRES.
2) ALL THROTTLE CONTROL WIRES ARE INCLUDED; HOWEVER, NOT ALL APPLICATIONS WILL UTILIZE ANY OR ALL OF THE WIRES.
3) INDICATING THAT EACH DRIVE HAS ITS OWN TRIM CONTROL SWITCH. THIS IS ONLY FOR APPLICATIONS WITH TRIPLE OR TRIPLE-DRIVE ONLY. TRIPLE-DRIVE ONLY UTILIZES ONE THROTTLE CONTROL WIRE ARE SYNCHRONIZED SET 1 FOR SINGLE.

DRAWING BY A.G.
AUGUST 2015


Chapter 3 - Complex Maintenance *(continued)*

Trim / Lift Electrical Drawing (24 Volt) single drive, single helm




Chapter 3 - Complex Maintenance *(continued)*

Trim / Lift Electrical Drawing (24 Volt) single drive, dual helm



Chapter 3 - Complex Maintenance (continued)

Trim / Lift Electrical Drawing (24 Volt) twin drive, single helm



NOTES:
1) WIRE IDENTIFICATIONS ARE LABELED AS BK=BLACK, BL=BLUE, RD=RED, PR=PURPLE, GR=GREEN, OR=ORANGE, WT=WHITE, GY=GRAY, YL=YELLOW, TN=TAN, BR=BROWN, PK=PINK
2) ALL WIRES PASSING THROUGH THE CONNECTORS REMAIN THE SAME COLOR


NOTE: CONDUCTORS NOT SHOWN ARE IDENTIFIED BY KONRAD MARINE
CONNECT TO NEGATIVE/GROUND SIDE OF 24VDC CIRCUIT
CONNECT TO POSITIVE SIDE OF 24VDC CIRCUIT (50 AMP)

NOTES FOR CONNECTOR 2:
1) ALL WIRES ARE RIGID AND TO BE ROUTED/CONNECTED TO DESIGNATED LOCATION.
2) ALL THROTTLE CONTROL WIRES ARE INSTALLED (BUT ARE NOT INCLUDED) IF YOUR APPLICATION HAS THROTTLE CONTROL. INSERT WIRES INTO DESIGNATED CAVITIES. IF YOUR APPLICATION DOES NOT UTILIZE ANY OR ALL OF THE THROTTLE CONTROL WIRES, SET 1 FOR SINGLE, SET 1,2 FOR TWIN, SET 1,2,3 FOR TRIPLE APPLICATION. THIS IS APPLICABLE TO EACH CAVITY HAS US OWN THROTTLE CONTROL SWITCH AND CAVITY APPLICATIONS. ALL CAVITIES MUST BE SYNCHRONIZED SET 1 FOR SINGLE CONTROL DRIVES ARE SYNCHRONIZED SET 1 FOR SINGLE.

CONNECTOR #	DESCRIPTION	WIRING CONNECTION
1	12 CAVITY MALE	13-445
2	12 CAVITY FEMALE	13-445
3	3 CAVITY 3 WAY FEMALE 2 CONNECTOR	13-445
4	12 CAVITY MALE	13-445
5	12 CAVITY FEMALE	13-445
6	12 CAVITY MALE	13-445
7	12 CAVITY FEMALE	13-445
8	12 CAVITY MALE	13-445
9	12 CAVITY FEMALE	13-445
10	12 CAVITY MALE	13-445
11	12 CAVITY FEMALE	13-445
12	12 CAVITY MALE	13-445
13	12 CAVITY FEMALE	13-445
14	12 CAVITY MALE	13-445

Chapter 3 - Complex Maintenance (continued)

Trim / Lift Electrical Drawing (24 Volt) twin drive, dual helm




Chapter 3 - Complex Maintenance *(continued)*

Trim / Lift Electrical Drawing (24 Volt) triple drive, single helm

CONNECTOR #	DESCRIPTION	MATING CONNECTOR
1	3 CAVITY FEMALE	3 CAVITY MALE
2	3 CAVITY FEMALE	3 CAVITY MALE
3	3 CAVITY FEMALE	3 CAVITY MALE
4	3 CAVITY FEMALE	3 CAVITY MALE
5	3 CAVITY FEMALE	3 CAVITY MALE
6	3 CAVITY FEMALE	3 CAVITY MALE
7	3 CAVITY FEMALE	3 CAVITY MALE
8	3 CAVITY FEMALE	3 CAVITY MALE
9	3 CAVITY FEMALE	3 CAVITY MALE
10	3 CAVITY FEMALE	3 CAVITY MALE
11	3 CAVITY FEMALE	3 CAVITY MALE
12	3 CAVITY FEMALE	3 CAVITY MALE
13	3 CAVITY FEMALE	3 CAVITY MALE
14	3 CAVITY FEMALE	3 CAVITY MALE
15	3 CAVITY FEMALE	3 CAVITY MALE
16	3 CAVITY FEMALE	3 CAVITY MALE
17	3 CAVITY FEMALE	3 CAVITY MALE
18	3 CAVITY FEMALE	3 CAVITY MALE
19	3 CAVITY FEMALE	3 CAVITY MALE
20	3 CAVITY FEMALE	3 CAVITY MALE
21	3 CAVITY FEMALE	3 CAVITY MALE
22	3 CAVITY FEMALE	3 CAVITY MALE
23	3 CAVITY FEMALE	3 CAVITY MALE
24	3 CAVITY FEMALE	3 CAVITY MALE
25	3 CAVITY FEMALE	3 CAVITY MALE
26	3 CAVITY FEMALE	3 CAVITY MALE
27	3 CAVITY FEMALE	3 CAVITY MALE
28	3 CAVITY FEMALE	3 CAVITY MALE
29	3 CAVITY FEMALE	3 CAVITY MALE
30	3 CAVITY FEMALE	3 CAVITY MALE

KONRAD MARINE INC.
TRIM SYSTEM ELECTRICAL
DRAWING (24 VOLT)
600B TRIPLE




- NOTES:**
- 1) WIRE IDENTIFICATIONS ARE LABELED AS: BK=BLACK, BL=BLUE, RD=RED, PR=PANEL ILLUMINATION, GR=GREEN, OR=ORANGE, TN=TAN, WH=WHITE, YL=YELLOW, YL=WHITE, GR=GRAY, RD=RED, BK=BLACK, GR=GREEN, TN=TAN, WH=WHITE, YL=YELLOW.
 - 2) ALL WIRE IDENTIFICATIONS ARE LABELED AS: BK=BLACK, BL=BLUE, RD=RED, TN=TAN, YL=YELLOW, GR=GREEN, WH=WHITE, GR=GRAY.
 - 3) SET 1 FOR SINGLE SET 1, 2 FOR TRIPLE SET 1, 2, 3 FOR TRIPLE SET 1, 2, 3.
 - 4) IF YOUR APPLICATION IS A TRIPLE OR TRIPLE BUT ONLY UTILIZES ONE THROTTLE CONTROL DRIVES ARE SYNCHRONIZED SET 1 FOR SINGLE.

DRAWING BY: A.G.
AUGUST 2015

Chapter 3 - Complex Maintenance *(continued)*

Trim / Lift Electrical Drawing (24 Volt) triple drive, dual helm

KONRAD MARINE INC.
TRIM SYSTEM ELECTRICAL
DRAWING (24 VOLT)
600B TRIPLE DUAL HELM



DRAWING BY: A.G.
AUGUST 2015

NOTES FOR HARNESS #1-054:
1) ALL THROTTLE CONTROL WIRES ARE INCLUDED; HOWEVER, NOT ALL APPLICATIONS WILL UTILIZE ALL OF THE WIRE FOR TRIM. SET 1, 2, 3 FOR TRIPLE APPLICATION. THIS IS INDICATING THAT EACH DRIVE HAS ITS OWN TRIM CONTROL SWITCH. THIS IS ONLY UTILIZES ONE THROTTLE CONTROL DRIVES ARE SYNCHRONIZED. SET 1 FOR SINGLE.

CONNECTING HARNESS FROM TRIM PUMP #2 & HARNESS FROM MODULE #3 (13-698)

CONNECTOR #	DESCRIPTION
1	1 - CAVITY FEMALE
2	2 - CAVITY FEMALE
3	3 - CAVITY FEMALE
4	4 - CAVITY FEMALE
5	5 - CAVITY FEMALE
6	6 - CAVITY FEMALE
7	7 - CAVITY FEMALE
8	8 - CAVITY FEMALE
9	9 - CAVITY FEMALE
10	10 - CAVITY FEMALE
11	11 - CAVITY FEMALE
12	12 - CAVITY FEMALE
13	13 - CAVITY FEMALE
14	14 - CAVITY FEMALE
15	15 - CAVITY FEMALE
16	16 - CAVITY FEMALE
17	17 - CAVITY FEMALE
18	18 - CAVITY FEMALE
19	19 - CAVITY FEMALE
20	20 - CAVITY FEMALE
21	21 - CAVITY FEMALE
22	22 - CAVITY FEMALE
23	23 - CAVITY FEMALE
24	24 - CAVITY FEMALE
25	25 - CAVITY FEMALE
26	26 - CAVITY FEMALE
27	27 - CAVITY FEMALE
28	28 - CAVITY FEMALE
29	29 - CAVITY FEMALE
30	30 - CAVITY FEMALE
31	31 - CAVITY FEMALE
32	32 - CAVITY FEMALE
33	33 - CAVITY FEMALE
34	34 - CAVITY FEMALE
35	35 - CAVITY FEMALE
36	36 - CAVITY FEMALE
37	37 - CAVITY FEMALE
38	38 - CAVITY FEMALE
39	39 - CAVITY FEMALE
40	40 - CAVITY FEMALE
41	41 - CAVITY FEMALE
42	42 - CAVITY FEMALE
43	43 - CAVITY FEMALE
44	44 - CAVITY FEMALE
45	45 - CAVITY FEMALE
46	46 - CAVITY FEMALE
47	47 - CAVITY FEMALE
48	48 - CAVITY FEMALE
49	49 - CAVITY FEMALE
50	50 - CAVITY FEMALE
51	51 - CAVITY FEMALE
52	52 - CAVITY FEMALE
53	53 - CAVITY FEMALE
54	54 - CAVITY FEMALE
55	55 - CAVITY FEMALE
56	56 - CAVITY FEMALE
57	57 - CAVITY FEMALE
58	58 - CAVITY FEMALE
59	59 - CAVITY FEMALE
60	60 - CAVITY FEMALE
61	61 - CAVITY FEMALE
62	62 - CAVITY FEMALE
63	63 - CAVITY FEMALE
64	64 - CAVITY FEMALE
65	65 - CAVITY FEMALE
66	66 - CAVITY FEMALE
67	67 - CAVITY FEMALE
68	68 - CAVITY FEMALE
69	69 - CAVITY FEMALE
70	70 - CAVITY FEMALE
71	71 - CAVITY FEMALE
72	72 - CAVITY FEMALE
73	73 - CAVITY FEMALE
74	74 - CAVITY FEMALE
75	75 - CAVITY FEMALE
76	76 - CAVITY FEMALE
77	77 - CAVITY FEMALE
78	78 - CAVITY FEMALE
79	79 - CAVITY FEMALE
80	80 - CAVITY FEMALE
81	81 - CAVITY FEMALE
82	82 - CAVITY FEMALE
83	83 - CAVITY FEMALE
84	84 - CAVITY FEMALE
85	85 - CAVITY FEMALE
86	86 - CAVITY FEMALE
87	87 - CAVITY FEMALE
88	88 - CAVITY FEMALE
89	89 - CAVITY FEMALE
90	90 - CAVITY FEMALE
91	91 - CAVITY FEMALE
92	92 - CAVITY FEMALE
93	93 - CAVITY FEMALE
94	94 - CAVITY FEMALE
95	95 - CAVITY FEMALE
96	96 - CAVITY FEMALE
97	97 - CAVITY FEMALE
98	98 - CAVITY FEMALE
99	99 - CAVITY FEMALE
100	100 - CAVITY FEMALE
101	101 - CAVITY FEMALE
102	102 - CAVITY FEMALE
103	103 - CAVITY FEMALE
104	104 - CAVITY FEMALE
105	105 - CAVITY FEMALE
106	106 - CAVITY FEMALE
107	107 - CAVITY FEMALE
108	108 - CAVITY FEMALE
109	109 - CAVITY FEMALE
110	110 - CAVITY FEMALE
111	111 - CAVITY FEMALE
112	112 - CAVITY FEMALE
113	113 - CAVITY FEMALE
114	114 - CAVITY FEMALE
115	115 - CAVITY FEMALE
116	116 - CAVITY FEMALE
117	117 - CAVITY FEMALE
118	118 - CAVITY FEMALE
119	119 - CAVITY FEMALE
120	120 - CAVITY FEMALE
121	121 - CAVITY FEMALE
122	122 - CAVITY FEMALE
123	123 - CAVITY FEMALE
124	124 - CAVITY FEMALE
125	125 - CAVITY FEMALE
126	126 - CAVITY FEMALE
127	127 - CAVITY FEMALE
128	128 - CAVITY FEMALE
129	129 - CAVITY FEMALE
130	130 - CAVITY FEMALE
131	131 - CAVITY FEMALE
132	132 - CAVITY FEMALE
133	133 - CAVITY FEMALE
134	134 - CAVITY FEMALE
135	135 - CAVITY FEMALE
136	136 - CAVITY FEMALE
137	137 - CAVITY FEMALE
138	138 - CAVITY FEMALE
139	139 - CAVITY FEMALE
140	140 - CAVITY FEMALE
141	141 - CAVITY FEMALE
142	142 - CAVITY FEMALE
143	143 - CAVITY FEMALE
144	144 - CAVITY FEMALE
145	145 - CAVITY FEMALE
146	146 - CAVITY FEMALE
147	147 - CAVITY FEMALE
148	148 - CAVITY FEMALE
149	149 - CAVITY FEMALE
150	150 - CAVITY FEMALE
151	151 - CAVITY FEMALE
152	152 - CAVITY FEMALE
153	153 - CAVITY FEMALE
154	154 - CAVITY FEMALE
155	155 - CAVITY FEMALE
156	156 - CAVITY FEMALE
157	157 - CAVITY FEMALE
158	158 - CAVITY FEMALE
159	159 - CAVITY FEMALE
160	160 - CAVITY FEMALE
161	161 - CAVITY FEMALE
162	162 - CAVITY FEMALE
163	163 - CAVITY FEMALE
164	164 - CAVITY FEMALE
165	165 - CAVITY FEMALE
166	166 - CAVITY FEMALE
167	167 - CAVITY FEMALE
168	168 - CAVITY FEMALE
169	169 - CAVITY FEMALE
170	170 - CAVITY FEMALE
171	171 - CAVITY FEMALE
172	172 - CAVITY FEMALE
173	173 - CAVITY FEMALE
174	174 - CAVITY FEMALE
175	175 - CAVITY FEMALE
176	176 - CAVITY FEMALE
177	177 - CAVITY FEMALE
178	178 - CAVITY FEMALE
179	179 - CAVITY FEMALE
180	180 - CAVITY FEMALE
181	181 - CAVITY FEMALE
182	182 - CAVITY FEMALE
183	183 - CAVITY FEMALE
184	184 - CAVITY FEMALE
185	185 - CAVITY FEMALE
186	186 - CAVITY FEMALE
187	187 - CAVITY FEMALE
188	188 - CAVITY FEMALE
189	189 - CAVITY FEMALE
190	190 - CAVITY FEMALE
191	191 - CAVITY FEMALE
192	192 - CAVITY FEMALE
193	193 - CAVITY FEMALE
194	194 - CAVITY FEMALE
195	195 - CAVITY FEMALE
196	196 - CAVITY FEMALE
197	197 - CAVITY FEMALE
198	198 - CAVITY FEMALE
199	199 - CAVITY FEMALE
200	200 - CAVITY FEMALE

Chapter 3 - Complex Maintenance *(continued)*

Setting the Trim/lift Range and Rudder Indicator


NOTE: *If your vessel is a twin or triple application that uses an external tie bar, you must disconnect the tie bar from the drives before proceeding.*

1. Turn power on to the trim gauge and trim system
The Main Menu will appear once power is supplied. Use the center arrow button to navigate down to the enter number of drives option, then press the button below the word “ENTER” on the screen to select..

NOTE: *To enter the main menu screen from the home screen, press the up arrow on the center directional button.*

NOTE: *If you are asked to enter a password, the default password code is 1111.*

2. Use the arrow key to scroll to the number of drives your vessel has. Once the correct number is shown on the screen, press the key below the word “ENTER”.
3. Press the key below the word “HOME” to go back to the main menu. Scroll down using the center directional key and select the calibrate system option.
4. Follow the on screen instructions to set the drive parameters. The first step is to set the zero trim position, (this is when the cavitation plate is level)
5. Trim the drive to the zero position, and press the key below the word enter on the trim control gauge. Once complete then the maximum, minimum trim, and rudder indicator will be set. Follow the on screen instructions to accomplish this.




Chapter 3 - Complex Maintenance *(continued)*

Setting the Trim/lift Range and Rudder Indicator


Note: Applications that have multiple drives will require each drive to be reconfigured, even if only one sensor is replaced.

Note: In multiple drive applications, the trim system refers to the drives by number (1,2,3). Drive number 1 by default is the drive on the port side, then proceeds towards the starboard side.



Note: If the sensor reading jumps around, it may be out of position. Check to ensure the sensor wires and indent on the shaft are aligned towards the front of the vessel.

Note: Complete sensor assembly has a part number of 31-053. (Includes sensor, wiring with connectors and transom fitting).




Chapter 3 - Complex Maintenance *(continued)*

Direct Mount tailpiece/engine alignment

1. Tool TO-189 is used to align the engine, transmission and tailpiece with the gimbal housing.

NOTE: *The sterndrive will have to be removed to complete these steps. Please refer to the sterndrive removal section in this manual.*




2. Slide the tailpiece alignment shaft (TO-189-A) all the way into the tailpiece output.




3. Hold the top portion of the alignment gauge against the flat surface on the top of the gimbal housing. Slide the gauge towards the back of the tailpiece until it is flush with the tailpiece.

Adjust the engine mounts until the gauge slides over the alignment shaft while sitting flush against the tailpiece housing, and the top of the gauge is up against the flat on the upper portion of the gimbal housing.



4. When the correct alignment is made, the alignment pin will be centered in the alignment gauge as shown in the picture to the right.



Chapter 3 - Complex Maintenance *(continued)*

Remote Mount driveshaft alignment

1. We suggest using tool (TO-186) to bolt onto the flange faces of the transmission and the gimbal housing to make measuring the distances easier. .

If aligning without Konrad tool (TO-186) then skip ahead to the NOTES and alignment specifications chart.



2. Place one of the alignment sticks onto the gimbal flange with the beveled edge facing away from the gimbal flange and fasten using two 13-625 H.H.C.S.




3. Take the remaining alignment stick and fasten it to the transmission output flange using two 13-716 bolts and two 11-247 nuts.



Chapter 3 - Complex Maintenance *(continued)*


Remote Mount driveshaft alignment

4. Rotate both flanges until the alignment sticks are in a vertical position..



5. Measure the distance between points A-B, C-D, and A-D, C-B
Adjust the engine mounts until the measured distance between points A-B and C-D are within .030 inches or .762mm. of each other.


See alignment specifications chart in the following pages.



Side view

6. Rotate the flanges until the sticks are horizontal and remeasure points A-B, C-D, A-D, and C-B

Adjust the engine mounts until the measured distances between the points A-B and C-D is within .030 inches or .762 mm. of each other.



Top view looking down

Chapter 3 - Complex Maintenance *(continued)*

Remote Mount driveshaft alignment

NOTE: It is recommended to hold either the horizontal or vertical offset at zero and achieve the offset in one plane. In most cases it is easier to hold the horizontal measurement at zero

7. Adjust the vertical or horizontal offset on measure points, A-D, and C-B.

Adjust the engine mounts until the distances between the two points A-D and C-B is within .047 - .094 inches or 1.19 - 2.39 mm. of each other for a standard Konrad (13-430) 9 inch shaft.

If your application is using another shaft, refer to the notes and chart below.

NOTES:

- 1) Transmission output flange and gimbal carrier input flange must be parallel within .030 inches or .762 mm.
- 2) Transmission output flange and gimbal carrier input flange must have a compounded vertical and horizontal offset angle (a) which is $1.0^\circ > (a) > 0.5^\circ$ in a u-joint shaft application.

CV shaft applications have a maximum of 2.0° compounded vertical and horizontal offset angle (a) which is $2.0^\circ > (a) > 1.0^\circ$.


This dimension is a function of the length of the shaft.

- 3) To determine vertical offset for a u-joint shaft, see picture below and use the following formula.

$$(x): x = \tan a (y - 3.0 \text{ in.}) \text{ or}$$
$$(x): x = \tan a (y - 7.62 \text{ cm})$$

- 4) To determine vertical offset for a CV shaft, use the following formula. (see picture below)

$$(x): x = \tan a (y - 5.04 \text{ in.}) \text{ or}$$
$$(x): x = \tan a (y - 12.8 \text{ cm})$$



Chapter 3 - Complex Maintenance *(continued)*

Alignment Specifications Chart for Transmission to Stern Drive Coupling

Coupling Type	Part #	Length (Range)	Parallelism	Concentricity	Axial Slip Compensation	Coupling Orientation	Tools Suggested	Torque (Fasteners)	Thread Lock Compound	Transmission Type	Stern Drive Carrier Type
Constant Velocity (CV)	31-044	>12.7 - <55 in. 32.3 - 140 cm	Max 2°	Max Offset 2°	.0625 in. 1.59 mm	N/A	GO-017 or TO-186 or TO-187	85 ft. lbs. 115 Nm	Yes	Output Flange	30-999
U-Joint Carden	13-430	>9 - <60 in. 23 - 152 cm	< .030 in. < .762 mm	Compound Offset between .5° < x < 1°	1 in. 25.4 mm	Yoke Orientation	GO-017 or TO-186 or TO-187	89 ft. lbs. 121 Nm	Yes	Output Flange	30-999



1421 Hanley Road
Hudson, Wisconsin 54016-9376 USA

Sales 715-386-4203
Toll Free 800-927-3545
Fax 715-386-4219

Website: www.konradmarine.com
E-mail: sales@konradmarine.com